

Providing innovative weight management solutions that improve the safety, productivity and profitability for professional truck drivers and transport companies for over 20 years.

#### About Right Weigh

Right Weigh was born from the need to have a simple and affordable solution for monitoring load weight. In 1998, Sid Campbell developed Right Weigh's first onboard gauges. As a fleet owner and operator in Alaska, Sid used his gauges on his own trucks and trailers. He recognized that many of his peers were also in search for the same solution. Since then, Right Weigh has become the go-to supplier of onboard load scales.

Right Weigh's gauges are designed and engineered by an experienced team with first-hand industry knowledge so our customers can work efficiently and lawfully. Right Weigh is committed to providing affordable, reliable gauges and excellent customer service. Whether you are an owner/operator, fleet owner, or OEM, Right Weigh gauges can save you time, save you money, and support your safety efforts.

## Contents

How It Works	5
AIR SUSPENSION	6
SPRING SUSPENSION	7
Product Numbering System	8
ANALOG GAUGES: (AIR SUSPENSION ONLY)	8
DIGITAL GAUGES: (AIR OR SPRING SUSPENSION)	9
Part Number Index	10
Application Charts	13
TRACTOR-TRAILER	14
Analog	14
Digital Gauges	16
Tractor Only	17
Trailer Only	20
Dedicated Tractor-Trailer Set	22
Drop & Hook	28
STRAIGHT TRUCK	
Analog Gauges	30
Digital Gauges	32
Products	35
201 SERIES-EXTERIOR DIGITAL	36
Air Suspension Tractor-Trailer	38
Air Suspension Straight Truck	42
Spring Suspension	43
202 SERIES—INTERIOR DIGITAL	44
250 SERIES-EXTERIOR ANALOG   2.5" LIQUID FILLED	46
310 SERIES-EXTERIOR ANALOG   3.5" DRY	48
400 SERIES-EXTERIOR ANALOG   4" LIQUID FILLED	50
510 SERIES-INTERIOR ANALOG	52
INSTALLATION KITS	54

Replacement Parts	57
Plumbing Diagrams	73
101-SK	74
102-SK	75
201-SK	76
301-QDK	77
Warranty	78

# Why Right Weigh load scales?

Right Weigh, Inc. is the go to supplier that you can trust. In order for our customers to work efficiently and lawfully, our load scales are designed and engineered by an experienced team with first-hand industry knowledge.

Our affordable and reliable load scale systems are built in-house from production to shipment. Whether you are an owner/operator, fleet owner or OEM, Right Weigh load scales can save you time, save you money and support your safety efforts.



#### Save more time

No more detours to commercial ground scales. The days of waiting in line to rework and weigh your loads are over.




#### Increase profits

Maximize load capacity and save money on commercial scale fees, out-of-route mileage and overweight fines.



#### Improve safety efforts

Remove the guess work out of driving and maintaining legal weights.



#### How it Works




## Air Suspension


Our scales work with most air suspension axle groups that use a height control valve. An axle group can consist of one, two, three, or four axles that are all connected together by one or two height control valves.


Height control valves, also called leveling valves, maintain a consistent ride height between the frame of the vehicle and the axles. When weight is applied or removed from the vehicle, the ride height changes. This change triggers the height control valve to increase or decrease the air pressure in the system in order to return the vehicle to the preset ride height.

#### Installation

Using a basic T-fitting, our scales connect to the vehicle's air suspension system to monitor the air pressure and display it as an accurate on-the-ground axle group weight. The diagrams to the right illustrate our scales installed on an air suspension axle group with one height control valve. For axle groups with two height control valves, two air lines are needed for installation.








#### How it Works

## Spring Suspension



Our spring suspension scales work with most spring suspension trailers and steer axles, as well as select types of drive axle suspensions.


As weight is added to the vehicle, the axles and other suspension components will bend slightly. This bend, or strain force, is measurable and repeatable and can be translated into changes in on-the-ground weight.



#### Installation

A strain sensor attaches to the axle or axle group to be monitored. On trailer, steer, and other non-driving axles, the sensor is typically placed on the top center of the axle. For drive axles, sensors are positioned offset from center on the axle itself or strategically placed on a load-bearing suspension component such as a walking beam, or single-point trunnion tube.

The strain sensor is attached by one of two methods. When attaching to axle tubes, single-point tunnion tubes, fabricated walking beams, or any other fabricated suspension component, welding is the preferred method of attachment. When attaching to a cast iron steer axle or any other cast iron suspension component, using epoxy to attach the sensor is preferred. See the diagram to the right for a basic overview of the strain sensor placement on a typical trailer axle.



# Product Numbering System

Right Weigh uses a meaningful product numbering system to help quickly identify the product and features. For gauges, the part number starts with a series name and is followed by type or feature identifiers separated by dashes. Accessory part numbers start with either a 3-digit number for the product series they apply to. For replacement parts and other components, the part number starts with a 2-letter code part type, followed by a 3-digit part sub-type, and ends with a 4-digit number.

Not all combinations are possible, however, for example, we don't make a 202-54-LM, so it is best to use this table if you want to decode a product you already have, a part number that you found in this book, or one that was recommended by a friend.

#### (AIR SUSPENSION ONLY)

**ANALOG GAUGES:** 

#### **SERIES NAME**

	250	2.5" Exterior Analog Liquid-Filled Gauge
	310	3.5" Exterior Analog Gauge
1	400	4" Exterior Analog Liquid-Filled Gauge
	510	2" Interior Analog Gauge

#### **MAX WEIGHT - APPLICATION**

30	30,000 LB – For Single Axle Groups Only
46	46,000 LB – For Tandem Axle Groups Only (510 series)
54	54,000 LB – For Tandem Axle Groups Only (400/310/250 Series)
HKANT40K	48,000 LB - For Tandem Axle Groups with Hendrickson VANTRAAX HKANT 40K or ULTRAA-K UTKNT 40K Air Suspension Only
64	64,000 LB - For Tri Axle Groups Only (250 Series)
80	80,000 LB - For Tri Axle Groups Only (310 Series)
16KG	16,000 KG - For Single Axle Groups Only
21KG	21,000 KG – For Tandem Axle Groups Only
25KG	25,000 KG - For Tandem Axle Groups Only (310 / 250 series)
ZONG	25,000 KG - For Tri Axle Groups Only (510 series)
30KG	30,000 KG - For Tri Axle Groups Only

#### **FEATURES**

GO	Gauge Only (310 Series)
PP	In Enclosure with Push-Pull Valve for Single Height Control Valve Suspension (1 Inlet Port)
M3	In Enclosure with Push-Pull Valve for Dual Height Control Valve Suspension (2 Inlet Ports)
LM	Lower Mount (250 series)
FF	Flange Mount (250 series)
RFB	Rear Flange Gauge in Enclosure Box (400 Series)
RF	Rear Flange Gauge (400 Series)
KF	

EXAMPLE
SERIES MAX WEIGHT- NAME APPLICATION
310 - 54 - PP
FEATURES
FEATURES

#### DIGITAL GAUGES: (AIR OR SPRING SUSPENSION)

#### **SERIES NAME** 201 Exterior Digital Gauge 202 Interior Digital Gauge EXAMPLE **FEATURE IDENTIFIER** EBT Exterior Bluetooth® 201-EBT-30B-WB All EDG gauges have been discontinued and replaced EDG with EBT gauges DDG Digital Dash Gauge RTS Remote Trailer System **NUMBER OF SPRING SENSORS** O Spring Sensors 1 Spring Sensor 2 2 Spring Sensors 3 3 Spring Sensors 4 Spring Sensors **NUMBER OF AIR SENSORS** 0 0 Air Sensors 1 1 Air Sensor 2 2 Air Sensors 3 3 Air Sensors 4 Air Sensors **OPTIONS** Blank Gauge Only (No Protective Enclosure) (201 Series) In Enclosure w/ Mounting Bracket & Hardware (201 Series) APPLICATION ADDENDUM TT Single Point Suspension WB Walking Beam Suspension

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Right Weigh, Inc. is under license. Other trademarks and trade names are those of their respective owners.

#### How it Works


## Part Number Index

PART NUMBER	OVERVIEW PAGE	DIAGRAM PAGE
101-SK	54	73
102-SK	54	74
201-219-10	See 201-EBT-10B	60
201-219-11	See 201-EBT-11B	60
201-219-12	See 201-EBT-12B	60
201-219-20	See 201-EBT-20B	60
201-219-21	See 201-EBT-21B	60
201-219-22	See 201-EBT-22B	60
201-219-30	See 201-EBT-30B	60
201-219-40	See 201-EBT-40B	60
201-257-01	See 201-RTS-01B	60
201-257-02	See 201-RTS-02B	60
201-BR	39	N/A
201-EBT-01	38	60
201-EBT-01B	38	60
201-EBT-02	39	60
201-EBT-02B	39	60
201-EBT-04B	40	60
201-EBT-10B	43	60,63
201-EBT-11B	42	60,64
201-EBT-12B	42	60-61,64
201-EBT-20B-TT	43	60,63-64
201-EBT-20B	43	60,63
201-EBT-21B	42	60-61,64
201-EBT-22B	42	58,60-61,64
201-EBT-30B	43	60-61,63
201-EBT-30B-WB	43	60,63-64
201-EBT-40B	43	60-61,63
201-RTS-01B	40	60-61, 65, 71
201-RTS-02B	40	60-61, 65, 71
201-SK	55	61
202-BR	45	N/A
202-DDG-01	44	62
202-DDG-02	44	62
202-DDG-03	44	62
202-DDG-04	44	62
211-SK	N/A	See 218-SK

PART NUMBER	OVERVIEW PAGE	DIAGRAM PAGE
218-SK	N/A	63
221-SK	N/A	64
224-SK	N/A	65
250-16KG-FF	46	66
250-16KG-LM	46	66
250-25KG-FF	46	66
250-25KG-LM	46	66
250-30-FF	46	66
250-30-LM	46	66
250-30KG-FF	46	66
250-30KG-LM	46	66
250-54-FF	46	66
250-54-LM	46	66
250-64-FF	46	66
250-64-LM	46	66
250-BR	47	N/A
250-HKANT40K-FF	46	66
250-HKANT40K-LM	46	66
301-QDK	55	67
310-16KG-M3	48	69
310-16KG-PP	48	68
310-25KG-M3	48	69
310-25KG-PP	48	68
310-30-M3	48	69
310-30-PP	48	68
310-30KG-M3	48	69
310-30KG-PP	48	68
310-54-M3	48	69
310-54-PP	48	68
310-80-M3	48	69
310-80-PP	48	68
310-HKANT40K-PP	48	68
310-SCK	49	N/A
400-54-RFB	50	70
510-16KG-B	52	N/A
510-16KG-C	52	N/A
510-25KG-B	52	N/A
510-25KG-C	52	N/A

PART NUMBER	OVERVIEW PAGE	DIAGRAM PAGE
510-30-B	52	N/A
510-30-C	52	N/A
510-30KG-B	52	N/A
510-30KG-C	52	N/A
510-46-B	52	N/A
510-46-C	52	N/A
510-B-BR	53	N/A
510-C-BR	53	N/A
EL-004-0049	See 201-RTS-01B	71
RTSK-01	41	71





Example installation of a 201 Digital Gauge on a spring suspension trailer



# APPLICATION CHARTS

#### KEY



TRACTOR ONLY | ESTIMATED STEER + DRIVE AXL



TRACTOR-ONLY | MEASURED STEER + DRIVE AXLE



TRAILER ONLY



TRACTOR-TRAILER | ESTIMATED STEER + DRIVE + TRAILE



TRACTOR-TRAILER | MEASURED STEER + DRIVE + TRAILER



STRAIGHT TRUCK | DRIVE AXLE



STRAIGHT TRUCK | STEER + DRIVE AXL



SPRING SUSPENSION



AIR SUSPENSION

#### **Application Charts**

# **Tractor-Trailer**Analog Gauges





Analog gauges monitor one air suspension axle group. These gauges are simple, easy to calibrate, and can be mounted on either a truck or trailer. The table on the following page can be used to find the correct gauge for any axle configuration starting with the number of axles in the axle group, specifying if there are one or two height control valves and whether an interior or exterior gauge is desired. Analog gauges work with air suspension axle groups only. For spring suspension applications please see the "Digital Gauge" section on page 16.

#### Right Weigh Analog Gauges

- » 250 Series: Exterior mount gauge, 2.5" diameter dial face
- » 310 Series: Exterior mount gauge, 3.5" diameter dial face
- » 400 Series: Exterior mount gauge, 4" diameter dial face
- » 510 Series: Interior mount gauge, 2" diameter dial face

To find out more information about each gauge, find the desired part number in the "Part Number Index" starting on page 10.

#### ANY AIR SUSPENSION AXLE GROUP



NUMBER OF AXLES	NUMBER OF HCV	INTERIOR/ EXTERIOR	GAUGE [LB]	GAUGE [KG]	INSTALLATION KIT(S)	
			510-30-B (Black)	510-16KG-B (Black)	101-SK	
		Interior	510-30-C (Chrome)	510-16KG-C (Chrome)	(Trailer axle group: 301-QDK)	
	1		250-30-LM	250-16KG-LM	101-SK	
		Exterior	250-30-FF	250-16KG-FF		
Single			310-30-PP	310-16KG-PP		
		Interior	510-30-B (Black) + 919-MINI-M3	510-16KG-B (Black) + 919-MINI-M3	(2) 101-SK (Trailer axle group: (2) 301- QDK)	
	2	interior	510-30-C (Chrome) + 919-MINI-M3	510-16KG-C (Chrome) + 919-MINI-M3		
		Exterior	310-30-M3	310-16KG-M3	(2) 101-SK	
		Interior	510-46-B (Black)	510-21KG-B (Black)	101-SK	
		Interior	510-46-C (Chrome)	510-21KG-C (Chrome)	(Trailer axle group: 301-QDK)	
			250-54-LM	250-25KG-LM	101-SK	
	1	Exterior	250-54-FF	250-25KG-FF		
			250-HKANT40K-LM*	N/A		
			250-HKANT40K-FF*			
Tandem			310-54-PP	310-25KG-PP		
			310-HKANT40K-PP*	N/A		
			400-54-RFB			
	2	Interior	510-46-B (Black) + 919-MINI-M3	510-21KG-B (Black) + 919-MINI-M3	(2) 101-SK (Trailer axle group:	
			510-46-C (Chrome) + 919-MINI-M3	510-21KG-C (Chrome) + 919-MINI-M3	(2) 301-QDK)	
		Exterior	310-54-M3	310-25KG-M3	(2) 101-SK	
	1	Interior	N/A	510-25KG-B (Black)	101-SK	
			N/A	510-25KG-C (Chrome)	(Trailer axle group: 301-QDK)	
		Exterior	250-64-FF	250-30KG-LM		
Tri-Axle			250-64-LM	250-30KG-FF	101-SK	
			310-80-PP	310-30KG-PP		
	2	Interior	N/A	510-25KG-B (Black) + 919-MINI-M3	(2) 101-SK	
			N/A	510-25KG-C (Chrome) + 919-MINI-M3	(Trailer axle group: (2) 301- QDK)	
		Exterior	310-80-M3	310-30KG-M3	(2) 101-SK	

 $<sup>^*</sup> For Tandem \ Axle \ Groups \ with \ Hendrickson \ VANTRAAX \ HKANT \ 40K \ or \ ULTRAA-K \ UTKNT \ 40K \ Air \ Suspension \ Only$ 

#### **Application Charts**

# **Tractor-Trailer**Digital Gauges

Digital gauges are more versatile, allowing the measurement of multiple axle groups, air and/or spring suspension, and having the capability of estimating the steer axle weight. They give the driver a numerical readout in 20 pound (or 10 kilogram) increments for air suspension and 100 pounds (or 50 kilogram) increments for spring suspension. Exterior gauges come standard with Bluetooth and can be purchased optionally with RS-232 connectivity.

#### Right Weigh Digital Gauges

- » 201 Series: Exterior gauge for air or spring suspension
- » 202 Series: Interior gauge for air suspension only

To find out more information about each gauge, find the desired part number in the "Part Number Index" starting on page 10.



Estimated Steer	24
Measured Steer	25
Air Suspension Steer   Air Suspension Drive	25
Spring Suspension Steer   Air Suspension Drive	26
Spring Suspension Steer   Air Suspension Drive	27
Drop & Hook	28

#### **Application Charts**

# Tractor Only

Right Weigh load scales are valuable for operators, fleets and OEMs.

## Steer Axle

If you want to know the weight of the steer axle, we have two available options: Estimated Steer or Measured Steer. Read below to find out which option is best for you.



#### **Estimated Steer**

Estimated Steer is just as it sounds, it gives an estimated readout of your steer axle weight without using a sensor on the steer axle. The way this works is the user inputs calibration data for the steer axle both empty and loaded. The scale associates the entered weights to the pressure or strain measured on the drive axle group at the time of calibration. Based on the data you input and the measurement from the drive axle group, the scale can calculate your steer axle weight. This feature is the best option for tractors with a fixed fifth wheel and is often more accurate than measuring the weight change with an air or strain sensor. This feature will not reliably work for straight trucks or anyone who slides their fifth wheel regularly. If you have a fixed fifth wheel or a slider that never moves, this option is for you.

\*Estimated Steer feature is not currently available for tractors with a spring suspension drive axle group.



#### **Measured Steer**

Measured Steer is the best option for drivers that slide their fifth wheel regularly. With this option, air or strain sensors are fitted to the steer axle to measure the change in weight. This works best on steer axles that see a significant weight change from empty to loaded. Erratic/unreliable weight readings can be expected on applications where the steer axle weight changes less than 1000lbs from empty to loaded. If you slide your fifth wheel regularly and see significant weight changes on your steer axle, this option is for you.

#### ESTIMATED STEER AIR SUSPENSION DRIVE AXLE GROUP





NUMBER OF HCV ON DRIVE AXLE GROUP	INTERIOR/EXTERIOR	BLUETOOTH-ENABLED	GAUGE	INSTALLATION KIT(S)
1	Interior	No	202-DDG-01	101-SK
1	Exterior	Yes	201-EBT-01B	201-SK
2	Interior	No	202-DDG-02	(2) 101-SK
	Exterior	Yes	201-EBT-02B	201-SK + 101-SK

#### MEASURED STEER AIR SUSPENSION DRIVE AXLE GROUP





STEER AXLE SUSPENSION TYPE	NUMBER OF HCV ON STEER AXLE (AIR)/ NUMBER OF STEER AXLES (SPRING)	NUMBER OF HCV ON DRIVE AXLE GROUP	INTERIOR/ EXTERIOR	BLUETOOTH- ENABLED	STEER GAUGE	DRIVE GAUGE	INSTALLATION KIT(S)
		1	Interior	No	202-DDG-02		(2) 101-SK
	1	1	Exterior	Yes	201-EBT-02B		201-SK + 101-SK
	1	2	Interior	No	202-DDG-03		(3) 101-SK
Air		2	Exterior	Yes	201-EBT-01B	201-EBT-02B	(2) 201-SK + 101-SK
Suspension		1	Interior	No	202-DDG-03		(3) 101-SK
	2		Exterior	Yes	201-EBT-02B	201-EBT-01B	(2) 201-SK + 101-SK
	2	2	Interior	No	202-DDG-04		(4) 101-SK
		2	Exterior	Yes	201-EBT-02B	201-EBT-02B	(2) 201-SK + (2) 101-SK
	1	1	Exterior	Yes	201-EBT-11B		
Spring	1	2	Exterior	Yes	201-EBT-12B		
Suspension	2	1	Exterior	Yes	201-EBT-21B		Included
		2	Exterior	Yes	201-EBT-22B		

#### **MEASURED STEER**SPRING SUSPENSION DRIVE AXLE GROUP





NUMBER OF STEER AXLES	DRIVE AXLE SUSPENSION TYPE	INTERIOR/EXTERIOR	BLUETOOTH- ENABLED	GAUGE	INSTALLATION KIT(S)	
4	Single Point	Exterior	Yes	201-EBT-20B-TT	la de de d	
1	Walking Beam	Exterior	Yes	201-EBT-30B-WB	Included	
2	Single Point	Exterior	Yes	Call fam Assallability		
	Walking Beam	Exterior	Yes	Call for Availability		

#### APPLICATION CHARTS

# Trailer Only

Our scales are versatile; they save time and money for operators and streamline commercial operations, productivity and efficiency.


20

#### AIR SUSPENSION TRAILER AXLE GROUP



NUMBER OF HCV	INTERIOR/EXTERIOR	BLUETOOTH-ENABLED	GAUGE	INSTALLATION KIT(S)
1	Exterior	Yes	201-EBT-01B	201-SK
2	Exterior	Yes	201-EBT-02B	201-SK + 101-SK

#### **SPRING SUSPENSION TRAILER AXLE GROUP**



NUMBER OF AXLES	INTERIOR/EXTERIOR	BLUETOOTH-ENABLED	GAUGE	INSTALLATION KIT(S)	
1	Exterior	Yes	201-EBT-10B	Included	
2	Exterior	Yes	201-EBT-20B	Included	
3	Exterior	Yes	201-EBT-30B	Included	
4	Exterior	Yes	201-EBT-40B	Included	

#### APPLICATION CHARTS

# Dedicated TractorTrailer Set

We have dealers all over the country that are already familiar with installing our products.
Check out our site's dealer locater tool to find a dealer near you.

## Steer Axle

If you want to know the weight of the steer axle, we have two available options: Estimated Steer or Measured Steer. Read below to find out which option is best for you.





#### **Estimated Steer**

Estimated Steer is just as it sounds, it gives an estimated readout of your steer axle weight without using a sensor on the steer axle. The way this works is the user inputs calibration data for the steer axle both empty and loaded. The scale associates the entered weights to the pressure or strain measured on the drive axle group at the time of calibration. Based on the data you input and the measurement from the drive axle group, the scale can calculate your steer axle weight. This feature is the best option for tractors with a fixed fifth wheel and is often more accurate than measuring the weight change with an air or strain sensor. This feature will not reliably work for straight trucks or anyone who slides their fifth wheel regularly. If you have a fixed fifth wheel or a slider that never moves, this option is for you.

\*Estimated Steer feature is not currently available for tractors with a spring suspension drive axle group.

#### **Measured Steer**

Measured Steer is the best option for drivers that slide their fifth wheel regularly. With this option, air or strain sensors are fitted to the steer axle to measure the change in weight. This works best on steer axles that see a significant weight change from empty to loaded. Erratic/unreliable weight readings can be expected on applications where the steer axle weight changes less than 1000lbs from empty to loaded. If you slide your fifth wheel regularly and see significant weight changes on your steer axle, this option is for you.

#### **ESTIMATED STEER**

#### AIR SUSPENSION DRIVE | AIR SUSPENSION TRAILER



NUMBER OF HCV ON DRIVE AXLE GROUP	NUMBER OF HCV ON TRAILER AXLE GROUP	INTERIOR/ EXTERIOR	BLUETOOTH- ENABLED	STEER GAUGE	DRIVE GAUGE	TRAILER GAUGE	INSTALLATION KIT(S)
	1	Interior	No	202-DDG-02			101-SK + 301-QDK
1		Exterior	Yes	201-EBT-02B		201-SK + 301-QDK	
1	2	Interior	No	202-DDG-03		101-SK + (2) 301-QDK	
		Exterior	Yes	201-EBT-01B		201-EBT-02B	(2) 201-SK + 101-SK
	4	Interior	No	202-DDG-03			(2) 101-SK + 301-QDK
2	1	Exterior	Yes	201-EBT-02B		201-EBT-01B	(2) 201-SK + 101-SK
2		Interior	No	202-DDG-04			(2) 101-SK + (2) 301-QDK
	2	Exterior	Yes	201-EBT-02B		201-EBT-02B	(2) 201-SK + (2) 101-SK

#### **ESTIMATED STEER**

AIR SUSPENSION DRIVE | SPRING SUSPENSION TRAILER (TWO GAUGES REQUIRED)—EXTERIOR GAUGES ONLY



NUMBER OF HCV ON DRIVE AXLE GROUP	NUMBER OF TRAILER AXLES	INTERIOR/ EXTERIOR	BLUETOOTH- ENABLED	STEER GAUGE	DRIVE GAUGE	TRAILER GAUGE	INSTALLATION KIT(S)	
	1	Exterior	Yes	201-EBT-01B		201-EBT-10B		
1	2	Exterior	Yes	201-EBT-01B		201-EBT-20B	201-SK	
1	3	Exterior	Yes	201-EBT-01B		201-EBT-30B	201-31	
	4	Exterior	Yes	201-EBT-01B		201-EBT-40B		
	1	Exterior	Yes	201-EBT-02B		201-EBT-10B		
2	2	Exterior	Yes	201-EBT-02B		201-EBT-20B	201-SK + 101-SK	
2	3	Exterior	Yes	201-EBT-02B		201-EBT-30B		
	4	Exterior	Yes	201-EBT-02B		201-EBT-40B		

#### **MEASURED STEER**

#### MEASURED STEER AIR SUSPENSION STEER | AIR SUSPENSION DRIVE | AIR SUSPENSION TRAILER



NUMBER OF HCV ON STEER AXLE GROUP	NUMBER OF HCV ON DRIVE AXLE GROUP	NUMBER OF HCV ON TRAILER AXLE GROUP	INTERIOR/ EXTERIOR	BLUETOOTH- ENABLED	STEER GAUGE	DRIVE GAUGE	TRAILER GAUGE	INSTALLATION KIT(S)
		1	Interior	No	202-DDG-03			(2) 101-SK + 301-QDK
	1		Exterior	Yes	201-EBT-02B		201-EBT-01B	(2) 201-SK + 101-SK
		2	Interior	No	202-DDG-04			(2) 101-SK + (2) 301-QDK
1		2	Exterior	Yes	201-EBT-02B		201-EBT-02B	(2) 201-SK +(2) 101-SK
		1	Interior	No	202-DDG-04			(3) 101-SK + 301-QDK
	2		Exterior	Yes	201-EBT-01B	201-EBT-02B	201-EBT-01B	(3) 201-SK + 101-SK
		2	Exterior	Yes	201-EBT-01B	201-EBT-02B	201-EBT-02B	(3) 201-SK + (2) 101-SK
		1	Interior	No	202-DDG-04			(3) 101-SK + 301-QDK
	1	1	Exterior	Yes	201-EBT-02B	201-EBT-01B	201-EBT-01B	(3) 201-SK + 101-SK
2		2	Exterior	Yes	201-EBT-02B	201-EBT-01B	201-EBT-02B	(2) 204 CV + (2) 404 CV
	2	1	Exterior	Yes	201-EBT-02B	201-EBT-02B	201-EBT-01B	(3) 201-SK + (2) 101-SK
	2	2	Exterior	Yes	201-EBT-02B	201-EBT-02B	201-EBT-02B	(3) 201-SK + (3) 101-SK

#### **MEASURED STEER**

AIR SUSPENSION STEER | AIR SUSPENSION DRIVE | **SPRING SUSPENSION TRAILER** (MULTIPLE GAUGES REQUIRED)—EXTERIOR GAUGES ONLY



NUMBER OF HCV ON STEER AXLE GROUP	NUMBER OF HCV ON DRIVE AXLE GROUP	NUMBER OF TRAILER AXLES	INTERIOR/ EXTERIOR	BLUETOOTH ENABLED	STEER GAUGE	DRIVE GAUGE	TRAILER GAUGE	INSTALLATION KIT(S)
		1	Exterior	Yes	201-EBT-02B		201-EBT-10B	
	1	2	Exterior	Yes	201-EBT-02B		201-EBT-20B	201-SK + 101-SK
	1	3	Exterior	Yes	201-EBT-02B		201-EBT-30B	201-3K + 101-3K
1		4	Exterior	Yes	201-EBT-02B		201-EBT-40B	
1		1	Exterior	Yes	201-EBT-01B	201-EBT-02B	201-EBT-10B	
		2	Exterior	Yes	201-EBT-01B	201-EBT-02B	201-EBT-20B	(2) 201-SK + 101-SK
	2	3	Exterior	Yes	201-EBT-01B	201-EBT-02B	201-EBT-30B	
		4	Exterior	Yes	201-EBT-01B	201-EBT-02B	201-EBT-40B	
		1	Exterior	Yes	201-EBT-02B	201-EBT-01B	201-EBT-10B	
	4	2	Exterior	Yes	201-EBT-02B	201-EBT-01B	201-EBT-20B	(0) 004 514 . 404 514
	1	3	Exterior	Yes	201-EBT-02B	201-EBT-01B	201-EBT-30B	(2) 201-SK + 101-SK
0		4	Exterior	Yes	201-EBT-02B	201-EBT-01B	201-EBT-40B	
2		1	Exterior	Yes	201-EBT-02B	201-EBT-02B	201-EBT-10B	
		2	Exterior	Yes	201-EBT-02B	201-EBT-02B	201-EBT-20B	(0) 004 CIV + (0) 404 CIV
	2	3	Exterior	Yes	201-EBT-02B	201-EBT-02B	201-EBT-30B	(2) 201-SK + (2) 101-SK
		4	Exterior	Yes	201-EBT-02B	201-EBT-02B	201-EBT-40B	

#### **MEASURED STEER**

SPRING SUSPENSION STEER | AIR SUSPENSION DRIVE |
AIR SUSPENSION TRAILER
(TWO GAUGES REQUIRED)—EXTERIOR GAUGES ONLY



NUMBER OF STEER AXLES	NUMBER OF HCV ON DRIVE AXLE GROUP	NUMBER OF HCV ON TRAILER AXLE GROUP	INTERIOR/ EXTERIOR	BLUETOOTH ENABLED	STEER GAUGE	DRIVE GAUGE	TRAILER GAUGE	INSTALLATION KIT(S)
	1	1	Exterior	Yes	201-EBT-11B		201-EBT-01B	201-SK
1	1	2	Exterior	Yes	201-EBT-11B	1-EBT-11B		201-SK + 101-SK
1	2	1	Exterior	Yes	201-EBT-12B		201-EBT-01B	201-SK
		2	Exterior	Yes	201-EBT-12B		201-EBT-02B	201-SK + 101-SK
	4	1	Exterior	Yes	201-EBT-21B		201-EBT-01B	201-SK
0	1	2	Exterior	Yes	201-EBT-21B		201-EBT-02B	201-SK + 101-SK
2		1	Exterior	Yes	201-EBT-22B		201-EBT-01B	201-SK
	2	2	Exterior	Yes	201-EBT-22B		201-EBT-02B	201-SK + 101-SK

#### **MEASURED STEER**

SPRING SUSPENSION STEER | AIR SUSPENSION DRIVE |
SPRING SUSPENSION TRAILER
(TWO GAUGES REQUIRED)—EXTERIOR GAUGES ONLY




NUMBER OF STEER AXLES	NUMBER OF HCV ON DRIVE AXLE GROUP	NUMBER OF TRAILER AXLES	INTERIOR/	BLUETOOTH	STEER GAUGE	DRIVE GAUGE	TRAILER GAUGE	INSTALLATION KIT(S)
		1	Exterior	Yes	201-EBT-11B		201-EBT-10B	
	1	2	Exterior	Yes	201-EBT-11B		201-EBT-20B	
	1	3	Exterior	Yes	201-EBT-11B		201-EBT-30B	
1		4	Exterior	Yes	201-EBT-11B		201-EBT-40B	Included
		1	Exterior	Yes	201-EBT-12B		201-EBT-10B	liicidded
	2	2	Exterior	Yes	201-EBT-12B		201-EBT-20B	
		3	Exterior	Yes	201-EBT-12B		201-EBT-30B	
		4	Exterior	Yes	201-EBT-12B		201-EBT-40B	
		1	Exterior	Yes	201-EBT-21B		201-EBT-10B	
	1	2	Exterior	Yes	201-EBT-21B		201-EBT-20B	
	1	3	Exterior	Yes	201-EBT-21B		201-EBT-30B	
2		4	Exterior	Yes	201-EBT-21B		201-EBT-40B	Included
2		1	Exterior	Yes	201-EBT-22B		201-EBT-10B	included
	2	2	Exterior	Yes	201-EBT-22B		201-EBT-20B	
		3	Exterior	Yes	201-EBT-22B		201-EBT-30B	
		4	Exterior	Yes	201-EBT-22B		201-EBT-40B	

#### **MEASURED STEER**







(TWO GAUGES REQUIRED)—EXTERIOR GAUGES ONLY

NUMBER OF STEER AXLES	DRIVE AXLE SUSPENSION TYPE	NUMBER OF HCV ON TRAILER AXLE GROUP	INTERIOR/ EXTERIOR	BLUETOOTH- ENABLED	STEER GAUGE	DRIVE GAUGE	TRAILER GAUGE	INSTALLATION KIT(S)	
		1	Exterior	Yes	201-EBT-20B-TT		201-EBT-01B	201-SK	
4	Single Point	2	Exterior	Yes	201-EBT-20B-TT		201-EBT-02B	201-SK + 101-SK	
1	Walking Beam	1	Exterior	Yes	201-EBT-30B-WB		201-EBT-01B	201-SK	
		2	Exterior	Yes	201-EBT-30B-WB		201-EBT-02B	201-SK + 101-SK	
	C: 1 D: 1	1	Exterior	Yes					
0	Single Point	2	Exterior	Yes					
2	Malling Dean	1	Exterior	Yes	Call for Availability				
	Walking Beam	2	Exterior	Yes					

#### **MEASURED STEER**

**SPRING SUSPENSION STEER | SPRING SUSPENSION DRIVE** | SPRING SUSPENSION TRAILER (TWO GAUGES REQUIRED)—EXTERIOR GAUGES ONLY





NUMBER OF STEER AXLES	DRIVE AXLE SUSPENSION TYPE	NUMBER OF TRAILER AXLES	INTERIOR/ EXTERIOR	BLUETOOTH- ENABLED	STEER GAUGE	DRIVE GAUGE	TRAILER GAUGE	INSTALLATION KIT(S)
		1	Exterior	Yes	201-EBT-20B-TT		201-EBT-10B	
	Single Point	2	Exterior	Yes	201-EBT-20B-TT		201-EBT-20B	
		3	Exterior	Yes	201-EBT-20B-TT		201-EBT-30B	
1		4	Exterior	Yes	201-EBT-20B-TT		201-EBT-40B	Included
		1	Exterior	Yes	201-EBT-30B-WI	3	201-EBT-10B	Included
	Malling Dage	2	Exterior	Yes	201-EBT-30B-WB		201-EBT-20B	
	Walking Beam	3	Exterior	Yes	201-EBT-30B-WB		201-EBT-30B	
		4	Exterior	Yes	201-EBT-30B-WB		201-EBT-40B	
		1	Exterior	Yes				
	Single Point	2	Exterior	Yes				
	Single Point	3	Exterior	Yes				
2		4	Exterior	Yes	Call for Availabilit	24		
2		1	Exterior	Yes	Call for Availabilit	.У		
	Walking	2	Exterior	Yes				
	Beam	3	Exterior	Yes				
		4	Exterior	Yes				

## Drop & Hook

Right Weigh has two available options for Drop & Hook situations.

#### **Option 1**

Install one gauge on each tractor and one gauge on each trailer in the fleet.

This is the required option if your fleet has any of the following:

- » tractors with spring suspension drive axles
- » spring suspension trailers
- » air suspension trailers with two height control valves
- » if the Measured Steer option is desired. (For more information on Measured Steer, see page 23.)

If any of these apply to you, please refer to the **Tractor Only** and **Trailer Only** sections to select the correct digital gauges for your vehicles.

#### **Option 2**

Install one gauge on each tractor to monitor both the truck and the trailer via a remote sensor installed on each trailer.

This is the most economical option for fleets with air suspension tractors and trailers. One gauge is required for each tractor and then only a sensor is affixed to each trailer. The tractor gauge is connected to the trailer sensor with a coiled cable when the driver hooks up. Calibration data for the trailer is stored on the remote sensor itself, allowing the gauge to show an accurate trailer weight when trailers are swapped from truck to truck. This option only works with air suspension drive and trailer axle groups.

An Estimated Steer axle weight can be displayed as well, but Measured Steer is not available. (For more information on Estimated Steer and Measured Steer, see page 23.) See the table below for Option 2 part number applications.

#### **DROP & HOOK**

NUMBER OF HCV ON DRIVE AXLE GROUP	NUMBER OF HCV ON TRAILER AXLE GROUP	INTERIOR/ EXTERIOR	BLUETOOTH- ENABLED	TRACTOR GAUGE	TRACTOR INSTALLATION KIT(S)	TRAILER SENSOR	TRAILER INSTALLATION KIT(S)
1	1	Exterior	Yes	201-RTS-01B	201-SK	RTSK-01	102-SK
2	1	Exterior	Yes	201-RTS-02B	201-SK + 101-SK	RTSK-01	102-SK

# Need your gauge installed on new equipment?

Right Weigh load scales are available as an optional equipment feature on most tractors and trailers. You can request that they be installed during manufacturing or as a pre-delivery option on new equipment. Ask your equipment dealer for more information.

We have working relationships with all the OEM's listed below. If you do not see your OEM in this list, please do not hesitate to contact us for further assistance. We are always willing to work with our customers.

- » Advance Pump & Equipment Inc.
- » Blackstone Trailer Company
- » Champion Carrier Corp.
- » CIMC Reefer Trailer Inc.
- » Dakota Manufacturing Co., Inc.
- » Doonan Specialized Trailer
- » East Manufacturing Co
- » Extreme Trailers
- » Great Dane Trailers
- » Hyundai Translead
- » Knapheide
- » Miller Industries
- » Utility Trailers
- » Landoll Corporation
- » Interstate Manufacturing
- » Mac Trailer Manufacturing
- » Manac
- » Manac Trailers USA, Inc.

- » Pitts (Dorsey) Trailers
- » Plutchak Fab, LLC
- » Reitnouer Trailers
- » Nelson Manufacturing
- » Strick Trailer, LLC
- » Talbert Manufacturing
- » Timpte, Inc.
- » Tornado Global Hydrovacs Ltd.
- » Trail King
- » Trailstar International
- » Trinity Trailer Mfg., Inc.
- » Vanguard National Trailer Center
- » Vantage Trailers, Inc.
- » Wabash National
- » Western Trailers
- » Whitley Truck Equipment
- » Superior Trailers of Georgia

#### **Application Charts**

# **Straight Truck**Analog Gauges





Analog gauges monitor one air suspension axle group. These gauges are simple and easy to calibrate. The table on the following page can be used to find the correct gauge for any axle configuration starting with the number of axles in the axle group, specifying if there are 1 or 2 height control valves, and whether an interior or exterior gauge is desired. Analog scales work with air suspension axles groups only.

For spring suspension applications please see the "Digital Gauge" section on page 32.

#### Right Weigh Analog Gauges

- 250 Series: Exterior mount gauge, 2.5" diameter dial face
- » 310 Series: Exterior mount gauge, 3.5" diameter dial face
- » 400 Series: Exterior mount gauge, 4" diameter dial face
- » 510 Series: Interior mount gauge, 2" diameter dial face

To find out more information about each gauge, find the desired part number in the "Part Number Index" starting on page 10.

#### ANY AIR SUSPENSION AXLE GROUP



NUMBER OF AXLES	NUMBER OF HCV	INTERIOR/ EXTERIOR	GAUGE [LB]	GAUGE [KG]	INSTALLATION KIT(S)	
		Interior	510-30-B (Black) 510-16KG-B (Black)		404 CV	
			510-30-C (Chrome) 510-16KG-C (Chrome)		101-SK	
	1	Exterior	250-30-LM 250-16KG-LM 250-30-FF 250-16KG-FF			
CiI-					101-SK	
Single			310-30-PP	310-16KG-PP		
			510-30-B (Black) + 919-MINI-M3	510-16KG-B (Black) + 919-MINI-M3		
	2	Interior	510-30-C (Chrome) + 919-MINI-M3	510-16KG-C (Chrome) + 919-MINI-M3	(2) 101-SK	
		Exterior	310-30-M3	310-16KG-M3	(2) 101-SK	
		Interior	510-46-B (Black)	510-21KG-B (Black)	404.01/	
			510-46-C (Chrome)	510-21KG-C (Chrome)	- 101-SK	
		Exterior	250-54-LM	250-25KG-LM		
			250-54-FF	250-25KG-FF	-	
Tandem	1		250-HKANT40K-LM*	N/A		
			250-HKANT40K-FF*		101-SK	
			310-54-PP	310-25KG-PP		
			310-HKANT40K-PP* N/A			
			400-54-RFB			
	2	Interior	510-46-B (Black) + 919-MINI-M3 510-21KG-B (Black) + 919-MINI-M3		(0) 404 014	
			510-46-C (Chrome) + 919-MINI-M3	510-21KG-C (Chrome) + 919-MINI-M3	(2) 101-SK	
		Exterior	310-54-M3	310-25KG-M3	(2) 101-SK	
	1	Interior	N/A	510-25KG-B (Black)	404 614	
Tri-Axle			N/A	510-25KG-C (Chrome)	- 101-SK	
		Exterior	250-64-FF	250-30KG-LM		
			250-64-LM 250-30KG-FF		101-SK	
			310-80-PP	310-30KG-PP	1	
	2	Interior	N/A	510-25KG-B (Black) + 919-MINI-M3	(0) 404 614	
			N/A	510-25KG-C (Chrome) + 919-MINI-M3	(2) 101-SK	
		Exterior	310-80-M3	310-30KG-M3	(2) 101-SK	

 $<sup>^*</sup>For Tandem \ Axle \ Groups \ with \ Hendrickson \ VANTRAAX \ HKANT \ 40K \ or \ ULTRAA-K \ UTKNT \ 40K \ Air \ Suspension \ Only$ 

#### **Application Charts**

# **Straight Truck**Digital Gauges





Digital gauges are more versatile allowing the measurement of multiple axle groups, for air and spring suspension applications. They give the driver a numerical readout in 20 pound (or 10 kilogram) increments for air suspension and 100 pounds (or 50 kilogram) increments for spring suspension. Exterior gauges come standard with Bluetooth and can be purchased optionally with RS-232 connectivity.


#### Right Weigh Digital Gauges

- » 201 Series: Exterior gauge for air or spring suspension
- » 202 Series: Interior gauge for air suspension only

To find out more information about each gauge, find the desired part number in the "Part Number Index" starting on page 10.

#### AIR SUSPENSION DRIVE AXLE GROUP





STEER AXLE SUSPENSION TYPE	NUMBER OF HCV ON STEER AXLE (AIR)/ NUMBER OF STEER AXLES (SPRING)	NUMBER OF HCV ON DRIVE AXLE GROUP	INTERIOR/ EXTERIOR	BLUETOOTH ENABLED	STEER GAUGE	DRIVE GAUGE	INSTALLATION KIT(S)
	1	1	Interior	No	202-DDG-02		(2) 101-SK
			Exterior	Yes	201-EBT-02B		201-SK + 101-SK
		2	Interior	No	202-DDG-03		(3) 101-SK
Air Suspension			Exterior	Yes	201-EBT-01B	201-EBT-02B	(2) 201-SK + 101-SK
Air Suspension	2	1	Interior	No	202-DDG-03		(3) 101-SK
			Exterior	Yes	201-EBT-02B	201-EBT-01B	(2) 201-SK + 101-SK
		2	Interior	No	202-DDG-04		(4) 101-SK
			Exterior	Yes	201-EBT-02B	201-EBT-02B	(2) 201-SK + (2) 101-SK
Spring Suspension	1	1	Exterior	Yes	201-EBT-11B		Included
		2	Exterior	Yes	201-EBT-12B		Included
	2	1	Exterior	Yes	201-EBT-21B Incl		Included
		2	Exterior	Yes	201-EBT-22B		Included

#### **SPRING SUSPENSION DRIVE AXLE GROUP**





NUMBER OF STEER AXLES	DRIVE AXLE SUSPENSION TYPE	INTERIOR/ EXTERIOR	BLUETOOTH-ENABLED	GAUGE	INSTALLATION KIT(S)
1	Single Point	Exterior	Yes	201-EBT-20B-TT	Included
	Walking Beam	Exterior	Yes	201-EBT-30B-WB	Included
2	Single Point	Exterior	Yes	Call for Availability	
	Walking Beam	Exterior	Yes		



# PRODUCTS

Here at Right Weigh we got our start by offering weight gauges specifically for tractors and trailers with air suspension. Since then we have expanded our product line many times over. In addition to our air suspension tractor-trailer gauges, we also have products for straight trucks with air suspension, trailers with leaf spring suspension, tractors or straight trucks with walking-beam suspension, tractors or straight trucks with Mack Camelback suspension, and twin steer trucks with air suspension drive axles.

As Right Weigh continues to grow, we will continue to provide reliable products at the most affordable pricing in the industry. As our number one priority, we will always provide the highest quality customer service.

# Exterior Digital Gauges 201 Series

The 201 series is a digital load scale designed to mount to the exterior of any tractor, trailer, or straight truck. Models are available for both air and spring suspension applications with Bluetooth standard and optional RS-232 data connectivity. Use in conjunction with the free Right Weigh Load Scales App to display weights on your smartphone or tablet. RS-232 connectivity allows weight data to be sent to onboard telematics systems.



#### » On-the-ground

**Features** 

- axle group weight shown in pounds or kilograms on an easy to read LCD display
- » Simple two-point (empty & loaded) calibration process makes it more accurate than a standard analog gauge
- » Estimated Steer axle weight calculated from air suspension drive axle group


- » Calibration can be PIN code protected
- » Overweight warning feature
- » Optional RS-232 connectivity allows communication with on-board telematics devices
- » Bluetooth-Enabled to display your weights on your Android or iOS device in real time, download our free app on Google Play and the App Store




#### **TECHINCAL SPECIFICATIONS**

Operating Temp.	-30° C to 85° C  -22°F to 185°F	
Storage Temp.	-40° C to 85° C  -40°F to 185°F	
Power	9 VDC to 32 VDC (Switched)	
Available Units	Kilograms (KG), Pounds (LB)	
Housing	High Impact Polycarbonate Blend	
Enclosure	Black Polypropylene	
Display	0.8" LCD Sunlight Readable	


#### **Product Identification**







### Air Suspension Tractor-Trailer

Installation One Axle Group







#### ONE AXLE GROUP

These gauges are designed for monitoring any air suspension axle group with one height control valve. Available with or without a weather-resistant enclosure.

- » Estimated Steer axle weight calculated from air suspension drive axle group
- » Up to four sets of calibration data can be stored for axle groups that have multiple operating configurations
- » Bluetooth and RS-232 connectivity





PART NO.	BLUETOOTH	RS-232	PROTECTIVE ENCLOSURE
201-EBT-01*	Yes	Yes	No
201-EBT-01B	Yes	Yes	Yes

<sup>\*</sup> These units should be mounted inside a tool box or other protective enclosure



Recommended Installation Kit(s):

» 201-SK

#### TWO AXLE GROUPS OR ONE GROUP WITH TWO HCVS

These gauges are designed for monitoring one axle group with two height control valves (HCV's), or two axle groups with one HCV each. Available with or without a weather-resistant enclosure.

» Estimated Steer axle weight calculated from air suspension drive axle group

- » Can be used on dedicated tractor-trailer sets with one HCV on the drive and one on the trailer
- » Up to four sets of calibration data can be stored for axle groups that have multiple operating configurations
- » Bluetooth and RS-232 connectivity





PART NO.	BLUETOOTH	RS-232	PROTECTIVE ENCLOSURE
201-EBT-02*	Yes	Yes	No
201-EBT-02B	Yes	Yes	Yes

<sup>\*</sup> These units should be mounted inside a tool box or other protective enclosure



Recommended Installation Kit(s):

- » 201-SK + 101-SK For applications with two separate axle groups on the same vehicle or one axle group with two HCVs.
- » 201-SK + 301-QDK For applications with two axle groups on separate vehicles, such as when monitoring both the tractor drive axle group and trailer axle group in a dedicated tractor-trailer set.

#### **201 BRACKET**

Optional mounting bracket for interior mounting of the 201 series gauges. Includes all necessary mounting hardware. Gauge and bracket are sold separately. Compatible only with 201 air suspension scales with one or two air sensors.



PART NO.	COMPATIBLE WITH
201-BR	201-EBT-01 201-EBT-02

#### **VOLVO ADAPTIVE LOADING**

This product was specifically designed for Volvo tractors with 6x2 Adaptive Loading suspension. It has four separate air sensors to monitor the weight supported by each of the drive axle suspension air bags.

- » Estimated Steer axle weight calculated from air suspension drive axle group
- » Bluetooth-Enabled. Used with app to display weight on your smart phone or tablet
- » RS-232 connectivity allows data to be sent to onboard telematics systems



PART NO.	BLUETOOTH	RS-232	PROTECTIVE ENCLOSURE
201-EBT-04B	Yes	Yes	Yes




Recommended Installation Kit(s):

» 201-SK + (3) 101-SK

### Drop & Hook


Installation Drop & Hook



#### **DROP & HOOK**

The 201-RTS product is our simple, economical drop and hook solution. The scale display is mounted on the tractor to monitor the drive axle suspension, calculate an Estimated Steer axle weight, and can be connected to any Right Weigh remote trailer sensor to also monitor the trailer axle group. These models are available in both one and two air sensor configurations, for tractor drive axle groups with either one or two Height Control Valves (HCV).

- » Bluetooth-Enabled. Used with app to display weight on your smartphone or tablet
- » RS-232 connectivity allows data to be sent to onboard telematics systems







Shown: 201-RTS-01B

PART NO.		BLUETOOTH	RS-232	PROTECTIVE ENCLOSURE	NUMBER OF HCV ON DRIVE AXLE GROUP	INSTALLATION KIT(S)
201-RTS-0	1B	Yes	Yes	Yes	1	201-SK
201-RTS-	)2B	Yes	Yes	Yes	2	201-SK + 101-SK

#### **REMOTE TRAILER SENSOR**

The RTSK-01 is the remote trailer sensor for use with the 201-RTS series scales. This sensor mounts to the trailer to monitor its axle group. Calibration is performed on the 201-RTS scale, but the calibration data is stored on the sensor

itself. This allows the trailer to be swapped from truck to truck and always read the correct weight. Only compatible with air suspensions controlled by one HCV.





PART NO.	COMPATIBLE WITH
RTSK-01	201-RTS-01B 201-RTS-02B



Recommended Installation Kit(s):

» 102-SK

### Air Suspension Straight Truck

#### SINGLE STEER AXLE

These gauges are designed for straight truck or tractor applications with an air suspension drive axle group and a spring suspension steer axle. They monitor the drive axle group as well as give a Measured Steer axle weight using a strain sensor that is attached to the steer axle. These work best in applications where the steer axle weight changes significantly depending on the load.

- » Available for drive axle groups with one or two HCVs
- » Bluetooth-Enabled. Used with app to display weight on your smartphone or tablet
- » Installation kits included





PART NO.	BLUETOOTH	RS-232	PROTECTIVE ENCLOSURE	NUMBER OF HCV ON DRIVE AXLE GROUP	INSTALLATION KIT(S)
201-EBT-11B	Yes	**	Yes	1	Included: 221-SK + 201-SK
201-EBT-12B	Yes	**	Yes	2	Included: 221-SK + 201-SK + 101-SK

<sup>\*\*</sup> Call for Availability

#### **DUAL STEER AXLE**

These gauges are designed for straight truck or tractor applications with an air suspension drive axle group and two spring suspension steer axles. They monitor the drive axle group as well as give a Measured Steer axle weight using a strain sensor that is attached to each steer axle. These work best in applications where the steer axle weight changes significantly depending on the load.

- » Available for drive axle groups with one or two HCVs
- » Bluetooth-Enabled. Used with app to display weight on your smartphone or tablet
- » Installation kits included





Shown: 201-219-21

PART NO.	BLUETOOTH	RS-232	PROTECTIVE ENCLOSURE	NUMBER OF HCV ON DRIVE AXLE GROUP	INSTALLATION KIT(S)
201-EBT-21B	Yes	**	Yes	1	Included: (2) 221-SK + 201-SK
201-EBT-22B	Yes	**	Yes	2	Included: (2) 221-SK + 201-SK + 101-SK

<sup>\*\*</sup> Call for Availability

### Spring Suspension

#### **STRAIGHT TRUCKS & TRACTORS**

The 201 series spring suspension scales are available for straight trucks and tractors with either single point or walking beam drive axle suspension.

- » Bluetooth-Enabled. Used with app to display weight on your smart phone or tablet
- » Installation kits included





Shown: 201-219-20

PART NO.	BLUETOOTH	RS-232	PROTECTIVE ENCLOSURE	DRIVE AXLE SUSPENSION TYPE	INSTALLATION KIT(S)
201-EBT-20B-TT	Yes	**	Yes	Single Point	Included: 221-SK + 218-SK
201-EBT-30B-WB	Yes	**	Yes	Walking Beam	Included: 221-SK + (2) 218-SK

<sup>\*\*</sup> Call for Availability

#### **TRAILERS**

Theses gauges are for monitoring the weight of any spring suspension trailer axle group. They are available in different configurations for trailers with one to four axles.

- » Bluetooth-Enabled. Used with app to display weight on your smartphone or tablet
- » Installation kits included





Shown: 201-219-40

PART NO.	BLUETOOTH	RS-232	PROTECTIVE ENCLOSURE	NUMBER OF AXLES	INSTALLATION KIT(S)
201-EBT-10B	Yes	**	Yes	1	Included: 218-SK
201-EBT-20B	Yes	**	Yes	2	Included: (2) 218-SK
201-EBT-30B	Yes	**	Yes	3	Included (3) 218-SK
201-EBT-40B	Yes	**	Yes	4	Included: (4) 218-SK

<sup>\*\*</sup> Call for Availability

# Interior Digital Gauges 202 Series

The 202 series is an interior digital scale designed for monitoring up to four air suspension axle groups with one height control valve (HCV) each, or a combination of axle groups with a total of four HCV's. This gauge is intended to mount inside the cab and fits into a standard 2-1/16" dash cutout.



- » On-the-ground axle group weight shown in pounds or kilograms on a touch screen LCD
- » Simple two-point (empty & loaded) calibration process makes it more accurate than a standard analog gauge
- » Estimated Steer axle weight calculated from air suspension drive axle group

- » Can be used on dedicated tractor-trailer sets
- » Calibration can be PIN code protected
- » Choice of black or chrome bezel colors included



PART NO.	TOTAL NUMBER OF HCV CONTROLLING MONITORED AXLE GROUPS
202-DDG-01	1
202-DDG-02	2
202-DDG-03	3
202-DDG-04	4





Recommended Installation Kit(s):


- » 101-SK (one kit required per HCV on tractor axle groups)
- » 301-QDK (one kit required per HCV on Trailer axle groups, or two per HCV if the application is a rear trailer in set of doubles)

# Summary (ib) Est. Steer \* Drive Trailer Cal Needed Summary (ib) Est. Steer \* Drive Trail(:) Total Cal Needed Cal Needed

#### **Product Identification**







#### TECHNICAL SPECIFICATIONS

Operating Temp.	-20° C to 85° C  -4°F to 185°F
Power	9 VDC to 32 VDC (Switiched)
Available units	Kilograms (KG), Pounds (LB)
Housing	ABS/PC Blend
Display	Capacitive Touch Screen

#### **202 BRACKET**

Optional mounting bracket for 202 series gauges. Includes all necessary mounting hardware. Gauge and bracket are sold separately.





PART NO.	COMPATIBLE WITH
202-BR	202 Series

# Exterior Analog Gauges 250 Series

The 250 series is an exterior analog scale designed for any air suspension axle group with one Height Control Valve (HCV). Choose between two different mounting styles, front flange or lower mount.

#### **Features**

- » On-the-ground axle group weight shown in pounds or kilograms on a touch screen LCD
- » 2.5" dial face, available in pound or kilograms
- » Corrosion-resistant, stainless steel construction
- » Liquid-filled to dampen vibration
- » Applications for single, tandem, and tri-axle

#### Lower Mount

The 250-LM is constructed with the air stem out the bottom. In this configuration, the air stem is the mounting attachment point.

#### Front Flange

The 250-FF utilizes a front flange to allow for flush mounting the gauge in place of an existing psi gauge on your tractor or trailer.



Flange Mount

PART NO.	NUMBER OF AXLES	UNITS
250-30-FF	Single	LB
250-HKANT40K-FF	Tandem**	LB
250-54-FF	Tandem	LB
250-64-FF	Tri Axle	LB
250-16KG-FF	Single	KG
250-25KG-FF	Tandem	KG
250-30KG-FF	Tri Axle	KG



Lower Mount

PART NO.	NUMBER OF AXLES	UNITS
250-30-LM	Single	LB
250-HKANT40K-LM	Tandem**	LB
250-54-LM	Tandem	LB
250-64-LM	Tri Axle	LB
250-16KG-LM	Single	KG
250-25KG-LM	Tandem	KG
250-30KG-LM	Tri Axle	KG

\*\*Tandem: Hendrickson VANTRAAX HKANT40K & ULTRAA-K UNKNT 40K




**Recommended Installation Kit:** 


» 101-SK

#### **Product Identification**


#### GAUGE



#### Lower Mount



Flange Mount



TECHINCAL SPECIFICATIONS

Operating Temp.	-40° C to 60° C  -40°F to 140°F
Available Units	Kilograms (KG), Pounds (LB)
Gauge Size	2.5"

#### **250 BRACKET**

Optional mounting bracket for both the 250-FF front flange and the 250-LM lower mount gauges. Includes mounting hardware. Gauge and bracket are sold separately.

PART NO.	COMPATIBLE WITH	
250-BR	250 Series	







# Exterior Analog Gauges 310 Series

The 310 series is an exterior analog scale designed for any air suspension axle group with one or two height control valves.



#### **Features**

- » 3.5" dial face, available in pound or kilograms
- » Push-pull on/off valve
- » Installed in a weather resistant enclosure
- » Mounting bracket and stainless steel hardware included

» Models available for single, tandem, and tri-axle groups

PART NO.	NUMBER OF AXLES	UNITS	NUMBER OF HCV'S
310-30-PP	Single	LB	1
310-30-M3	Single	LB	2
310-54-PP	Tandem	LB	1
310-54-M3	Tandem	LB	2
310-HKANT40K-PP	Tandem**	LB	1
310-80-PP	Tri Axle	LB	1
310-80-M3	Tri Axle	LB	2
310-16KG-PP	Single	KG	1
310-16KG-M3	Single	KG	2
310-25KG-PP	Tandem	KG	1
310-25KG-M3	Tandem	KG	2
310-30KG-PP	Tri Axle	KG	1
310-30KG-M3	Tri Axle	KG	2
B310-30KG-PP*	Tri Axle	KG	1
B310-30KG-M3*	Tri Axle	KG	2

\*\*Tandem: Hendrickson VANTRAAX HKANT40K & ULTRAA-K UNKNT 40K




Recommended Installation Kit(s):

» 101-SK (Axle groups with two HCV's require two installation kits)

### 

# 7.56in



#### **TECHNICAL SPECIFICATIONS**

Operating Temp.	-40° C to 85° C  -40°F to 185°F
Available Units	Kilograms (KG), Pounds (LB)
Enclosure	Black Polyprolylene
Gauge Size	3.5"

#### **Product Identification**

#### **AIR BAG DIAMETER**

		Blank	Standard - Diameter of Less Than 13.75" (340mm)	
		В	Large - Diameter of 13.75" (340mm) or Larger	
GAUGE		GAUGE	-	
		310	3.5" Exterior Analog	
		MAXIMUM WEIGHT READING		
		30	30,000 LB - For Single Axle Groups Only	
		54	54,000 LB - For Tandem Axle Groups Only	
		HKANT40K	48,000 LB - For Tandem Axle Groups with Hendrickson VANTRAAX HKANT40K or UL- TRAA-K UNKNT 40K Air Suspension Only	
		80	80,000 LB - For Tri Axle Groups Only	
		16KG	16,000 KG - For Single Axle Groups Only	
25k		25KG	25,000 KG - For Tandem Axle Groups Only	
		30KG	30,000 KG - For Tri Axle Groups Only	
		FEATURE IDE	NTIFIER	
		GO	Gauge Only	
		PP	In Enclosure with Push-Pull Valve for Single Height Control Valve Suspension (1 Inlet Port)	
		М3	In Enclosure with Push-Pull Valve for Dual Height Control Valve Suspension (2 Inlet Ports)	
	L		<del>,                                    </del>	
		<b>D</b> 2	10-30KG-PP	
		DJ	TO-SOLG-LL	

#### **310 SECURITY COVER**

Optional security cover kit for 310 series gauges. Uses security seals to ensure calibration screw is not tampered with. Gauge and security cover are sold separately.

PART NO.	COMPATIBLE WITH	
310-SCK	310 Series	



# Exterior Analog Gauges 400 Series

The 400 series is an exterior analog scale designed for monitoring an air suspension axle group with one Height Control Valve (HCV). Currently only available for tandem axle groups.



# 7.24in

15.94in

4.50in

#### **Features**


- » 4" dial face, largest of all gauges we offer
- » Stainless steel construction resists corrosion
- » Liquid filled to dampen vibration
- » Installed in a weather resistant enclosure
- » Mounting bracket and stainless steel mounting hardware included
- » Dual unit, reads in both pounds (LB) and kilograms (KG)

PART NO.	COMPATIBLE WITH	
400-54-RFB		



Recommended Installation Kit(s):

» 101-SK



#### TECHINCAL SPECIFICATIONS

Operating Temp.	-20° C to 60° C  -4°F to 140°F
Available Units	Kilograms (KG), Pounds (LB)
Enclosure	Black Polyprolylene
Gauge Size	4"

### Analog vs Digital, Which is Right for Me?

If your goal is simply to maintain legal axle weights than many times choosing between analog and digital is just a matter of personal preference. Our analog gauges are super simple and work great for drivers with air suspension who just need to maintain legal axle group weights and avoid overweight fines. A digital gauge is required if the vehicle does not have air suspension, is used for heavy haul applications, or if lift axles are involved. Our digital gauges use two-point calibration, once while empty and once while loaded, making them more accurate for partial loads. Exterior digital models also work for axle groups with multiple configurations, such as groups with integrated lift axles, come standard with Bluetooth connectivity, and can be purchased optionally with RS-232 output for use with telematics systems.

If you need some help finding the right gauge for your application, please call us at (503) 628-0838 or (888)818-2058 (toll free-inside the US only).



# Interior Analog Gauges 510 Series

The 510 series is an interior analog scale designed for monitoring air suspension axle groups with one Height Control Valve (HCV). With the use of an additional splitter valve (919-MINI-M3), these gauges can also be used on axle groups with two HCVs. This gauge is intended to mount inside the cab and fits into a standard 2-1/16" dash cutout.

#### **Features**

- » 2" dial face, available in pounds or kilograms
- » Applications for single, tandem, and tri-axle (tri-axle only available in kilograms dial face)
- » Choice of black or chrome bezel colors
- » 7-Color selectable LED backlight






PART NO.	NUMBER OF AXLES	UNITS	BEZEL COLOR
510-30-B	Single	LB	Black
510-30-C	Single	LB	Chrome
510-46-B	Tandem	LB	Black
510-46-C	Tandem	LB	Chrome
510-16KG-B	Single	KG	Black
510-16KG-C	Single	KG	Chrome
510-25KG-B	Tandem	KG	Black
510-25KG-C	Tandem	KG	Chrome
510-30KG-B	Tri Axle	KG	Black
510-30KG-C	Tri Axle	KG	Chrome



Recommended Installation Kit(s):

» 101-SK (Axle groups with two HCV's require two installation kits)



#### **TECHINCAL SPECIFICATIONS**

Operating Temp.	-40° C to 85° C  -40°F to 185°F
Available Units	Kilograms (KG), Pounds (LB)
Bezel Color Options	Black (B), Chrome (C)
Gauge Size	2"

#### **Product Identification**



	5	510	2" Interior Analog Load Scale			
	MAXIMUM WEIGHT READING					
	3	80	30,000 LB - For Single Axle Groups Only			
	4	16	46,000 LB - For Tandem Axle Groups Only			
Г	1	.6KG	16,000 KG - For Single Axle Groups Only			
	2	25KG	25,000 KG - For Tandem Axle Groups Only			
30KG 30		80KG	30,000 KG - For Tri Axle Groups Only			
	_	COLOR				
١.	E	3	Black			
	C	C	Chrome			
L'						
		Γ				
			51U-46-C			

#### **510 BRACKET**

Optional mounting bracket for 510 series gauges. Available in black or chrome finish. Gauge and bracket are sold separately.

PART NO.	FINISH	COMPATIBLE WITH
510-B-BR	Black	510 Series
510-C-BR	Chrome	510 Series





#### **SPLITTER FOR TWO HCV'S**

This splitter valve is designed to allow the 510 series gauges to work on air suspension axle groups with two Height Control Valves. Gauge and valve are sold separately.

PART NO.	COMPATIBLE WITH
919-MINI-M3	510 Series



### Installation Kits

#### **SCALE TO SUSPENSION AIR BAG**

This kit is designed to connect any Right Weigh scale to a suspension air bag.

#### PART NO.

101-SK



1/4" Male NPT Elbow Fitting




1/8" Female NPT Elbow Fitting



3/8" NPT to 1/4" NPT Reducer Fitting



3%" NPT Street Tee Fitting



1/4" NPT

Street Tee Fitting

1/4" Air Line Qty: 30 feet





#### REMOTE TRAILER SENSOR TO SUSPENSION AIR BAG

This kit is designed to connect a Right Weigh remote trailer sensor to a suspension air bag.




102-SK



3/8" NPT Street Tee Fitting



1/4" NPT Street Tee Fitting



1/4" Air Line Qty: 60 feet

Zip Ties Qty: 30

#### **SCALE TO SUSPENSION AIR BAG + ELECTRICAL**

This kit is designed to connect a digital exterior scale to a suspension air bag and a 12v or 24v power source.

1/4" Male NPT

Straight Fitting

PART NO.

201-SK



3/8" NPT Street Tee Fitting



1/4" NPT Street Tee Fitting






Crimp & Seal



Butt Connectors



%" NPT to 1/4" NPT Reducer Fitting




1/4" Air Line Qty: 30 feet



½" x 6" Heat Shrink Tube





Power Cable Qty: 25 feet

#### TRUCK SCALE TO TRAILER SUSPENSION AIR BAG

This kit is designed to connect any truck mounted Right Weigh scale to a trailer suspension air bag.




3/8" NPT to 1/4" NPT Reducer Fitting



**Bulkhead Fitting** Qty: 2



Male Quick Disconnect with 1/4" Female NPT



1/4" Air Line Qty: 80 feet



PART NO.

301-QDK


3/8" NPT Street Tee Fitting



Female Quick Disconnect with 1/4" Male NPT



1/4" Male NPT Straight Fitting Qty: 3



25 ft. Coiled Air Line with Male **NPT Ends** 



1/4" NPT Street Tee Fitting



Zip Ties Qty: 40

©Right Weigh, Inc. 2021 55



# REPLACEMENT PARTS

Each replacement part is sold separately and can be purchased directly from Right Weigh, Inc.
Right Weigh uses a meaningful part numbering system to help quickly identify each part individually.
For replacement parts, each number starts with a 2-letter code that stands for a category (electrical —EL, hardware bags —HB, etc.). This is then followed by a 3-number feature identifier specific to that category.
The part is then given a 4-number sequence that is specific to that part.


#### CATEGORY

EL	Electrical
EN	Enclosures
НВ	Hardware Bags
HW	Hardware (Brackets, Bolts)
LC	Liquid (Epoxy, Adhesives, Silicone)
мм	Marketing Material
PF	Pressure Fittings
PN	Pneumatic (Valves)
PP	Product Packaging (Stickers, Instructions, Manuals)
	EN HB HW LC MMM PF


FEATURE IDENTIFIER 1

FEATURE IDENTIFIER 2

EL-004-0025




REPLACEMEN	IT PARTS	REPLACEMENT PARTS KIT		
Reference #	Part Number	Part Description	Quantity	HB-002-0001
1	HW-009-0207	Zip Tie: 7" Black Nylon	15	
2	PN-004-0002	Air Line: ¼" x 0.17" Black Polyethylene, 30 Ft	1	
3	PF-001-0002	Street Tee Fitting: 3/8 NPT (Brass)	1	Х
4	PF-001-0011	Street Tee Fitting: ¼ NPT (Brass)	1	X
5	PF-001-0006	Tube Fitting: ¼" Tube to ¼-NPT Male Elbow (Brass)	1	Х
6	PF-001-0007	Tube Fitting: ¼" Tube to 1/8 NPT Female Elbow (Brass)	1	X
7	PF-001-0013	Tube Fitting: ¼" Tube to ¼ NPT Male Straight (Brass)	1	Х
8	PF-001-0003	Bushing: 3/8 NPT Male to ¼ NPT Female (Brass)	1	Х
N/A	PP-003-0007	Instruction Manual: 101-SK	1	



REPLACEMEN	T PARTS	REPLACEMENT PARTS KIT		
Reference #	Part Number	Part Description	Quantity	HB-002-0009
1	PN-004-0004	Air Line: ¼" x 0.170" Black Polyethylene, 60 Ft	1	
2	HW-999-0207	Zip Tie: 7" (Black Nylon)	30	
3	PF-001-0002	Street Tee Fitting: 3/8 NPT (Brass)	1	X
4	PF-001-0011	Street Tee Fitting: 1/4 NPT (Brass)	1	X
5	PF-001-0013	Tube Fitting: ¼" Tube to ¼ NPT Male Straight (Brass)	1	Х
6	PF-001-0003	Bushing: 3/8 NPT Male to ¼ NPT Female (Brass)	1	Х
N/A	PP-003-0035	Instruction Manual: 102-SK	1	


#### 201 SERIES



REPLACEMENT PARTS			REPLACEMENT PARTS KITS			
Reference #	Parts Number	Part Description	Quantity	HB-001-0000	909-BR	909-201-K
1	HW-001-0001	Mounting Bracket	1		Х	Х
2	HW-004-1401	Nylon Insert Lock Nut: ¼-20 (18-8 Stainless Steel)	4	X	X	X
3	HW-004-3801	Nylon Insert Lock Nut: 3/8-16 (18-8 Stainless Steel)	2	X	Х	X
4	HW-002-0003	Hex Cap Screw: 3/8-16 x 1 (18-8 Stainless Steel)	2	Х	Х	Х
5	HW-003-0003	Flat Washer: 3/8" (18-8 Stainless Steel)	2	Х	Х	Х
6	HW-003-0001	Flat Washer: ¼" (18-8 Stainless Steel)	4	X	X	X
7	HW-002-0002	Hex Cap Screw: ¼-20 x ¾ (18-8 Stainless Steel)	4	x	X	X
8	909-201	Exterior Enclosure Box	1			Х
9	HW-001-0005	Machine Screw: 8-32 x 5/8" Flat Head Philips Undercut (18-8 Stainless Steel)	4			х
10	HW-009-0203	201 Mounting Gasket	1			X
11*	PF-002-0001	Push-to-Connect Fitting: ¼" Tube to 10-32 Male Straight (Nickel Pated Brass)	**			
12	HW-004-0003	Nylon Insert Lock Nut: 8-32 (18-8 Stainless Steel Wax Coated)	1			X


<sup>\*</sup>Air suspension only

<sup>\*\*</sup>Quantity varies between product numbers



REPLACEMEN <sup>*</sup>	REPLACEMENT PARTS KIT			
Reference #	Part Number	Part Description	Quantity	HB-002-0002
1	EL-006-0000	Butt Connector: Crimp and Seal (16-14 AWG to 22-18 AWG Blue)	2	X
2	EL-006-0005	Butt Connector: Crimp and Seal (20-18 AWG Red)	2	X
3	PF-001-0011	Street Tee Fitting: 3/8 NPT (Brass)	1	X
4	PF-001-0002	Street Tee Fitting: ¼ NPT (Brass)	1	X
5	PF-001-0013	Tube Fitting: ¼" Tube to ¼ NPT Male Straight (Brass)	1	Х
6	PF-001-0003	Bushing: 3/8-NPT Male to ¼ NPT Female (Brass)	1	X
7	EL-004-0004	Power Cable (25 Feet)	1	
8	EL-006-0007	Heat Shrink Tube: ½" x 6" w/ Adhesive (Black)	2	
9	HW-999-0207	Zip Tie: 7" Black	30	
10	PN-004-0002	Air Line: ¼" x 0.17" Black Polyethylene, 30 Ft	1	
N/A	PP-003-0008	Instruction Manual: 201-SK	1	


#### **202 SERIES**



#### REPLACEMENT PARTS


Reference #	Part Number	Description	Quantity
1	HW-001-0228	Thread-Forming Screw: 2-28 x ¼" Phillips Head, for Plastic (Zinc-Plated Steel)	4
2	HW-001-0010	Machine Screw: 4-40 x ½" Flat Head Phillips Machine Screw (18-8 Stainless Steel)	4
3	PF-002-0001	Push-to-Connect Fitting: ¼" Tube to 10-32 Male Straight (Nickel Pated Brass)	**
4	EN-003-0201	Threaded Nut	1
N/A	EL-004-0010	Connector Cable, 600 mm	1

<sup>\*\*</sup>Quantity varies between product numbers




#### REPLACEMENT PARTS REPLACEMENT PARTS KIT

Reference #	Part Number	Part Description	Quantity	HB-003-0006
1	EL-004-0054	Strain Sensor Pickup Coil	1	
2	EL-001-0002	Tension Bar	1	
3	EL-006-0007	Heat Shrink Tube: ½" x 6" w/ Adhesive (Black)	2	Х
4	HW-010-0052	Sensor Mounting Block Welding Jig Assembly	1	
5	HW-010-0040	Metal Cover for Strain Sensor Bar Assembly	1	
6	EL-004-0055	Extension Harness (25 Feet)	1	
7	EL-006-0005	Butt Connector: Crimp and Seal (20-18 AWG Red)	2	Х
8	HW-011-0006	Loop Clamp: 3/16" ID, 1-1/6" Long	1	x
9	HW-001-0015	Hex Cap Screw: ¼-20 x ½ (18-8 Stainless Steel)	1	x
10	HW-003-0001	Flat Washer: ¼" (18-8 Stainless Steel)	1	x
11	HW-999-0210	Zip Tie: 11" Black Nylon	4	X
12	HW-999-0207	Zip Tie: 7" Black Nylon	15	x
13	HW-011-0007	Worm Drive Hose Clamp: 4" - 9-1/s" Diameter (Vibration Resistant)	1	
14	HW-011-0000	Worm Drive Hose Clamp: 29/32" Maximum Diameter	1	Х
N/A	PP-003-0045	Instruction Manual: 218-SK	1	



REPLACEMENT PARTS				
Reference #	Part Number	Part Description	Quantity	HB-003-0006
1	EL-001-0002	Tension Bar	1	
2	EL-004-0054	Strain Sensor Pickup Coil	1	
3	EL-006-0007	Heat Shrink Tube: ½" x 6" w/ Adhesive (Black)	2	Х
4	HW-001-0001	Set Screw: ¼-28 x ¼" Hex Drive (Stainless Steel)	3	
5	HW-010-0044	Mounting Block, Open Side (2 Set Screw Holes)	1	
6	HW-010-0046	Mounting Block, Closed Side (1 Set Screw Hole)	1	
7	HW-010-0016	Alignment Dowel	1	
8	EL-004-0055	Extension Harness (25 Feet)	1	
9	HW-010-0047	Metal Cover for Strain Sensor Bar Assembly (Steel 18 Gauge)	1	Х
10	EL-006-0005	Butt Connector: Crimp and Seal (20-18 AWG Red)	2	X
11	HW-011-0006	Loop Clamp: ¾16" ID, 1-1/8" Long	1	X
12	HW-001-0015	Hex Cap Screw: 1/20 x 1/2 (18-8 Stainless Steel)	1	Х
13	HW-003-0001	Flat Washer: ¼" (18-8 Stainless Steel)	1	X
14	HW-011-0007	Worm Drive Hose Clamp: 4" – 9 1/8" Diameter (Vibration Resistant)	1	
15	HW-011-0004	Worm Drive Hose Clamp: 4" – 6-1/6" Diameter (Vibration Resistant)	2	
16	HW-011-0000	Worm Drive Hose Clamp: 29/32" Maximum Diameter	1	X
17	HW-999-0210	Zip Tie: 11" Black Nylon	4	Х
18	HW-999-0207	Zip Tie: 7" Black Nylon	15	Х
N/A	PP-003-0043	Instruction Manual: 221-SK	1	



REPLACEMENT PARTS			REPLACEMENT PARTS KIT		
Reference #	Part Number	Part Description	Quantity	HB-001-0006	
1	EL-004-0040	Remote Trailer Scale to Socket Harness (w/ Socket)	1		
2	HW-002-0005	Screw: 5/16-18 x 1", Hex Cap (18-8 Stainless Steel)	2	X	
3	HW-003-0007	Washer: 5/16", Flat (18-8 Stainless Steel)	2	X	
4	HW-004-0004	Lock Nut: 5/16-18 Nylon Insert (18-8 Stainless Steel)	2	Х	


#### 250-FF



#### REPLACEMENT PARTS

Reference #	Part Number	Part Description		
	GO250-16KG-FF	16,000 KG - For Single Axle Groups Only		
	GO250-25KG-FF	25,000 KG – For Tandem Axle Groups Only		
	GO250-30KG-FF	30,000 KG – For Tri-Axle Groups Only		
	GO250-30-FF	30,000 LB - For Single Axle Groups Only		
1	GO250-54-FF	54,000 LB - For Tandem Axle Groups Only		
	GO250-64-FF	64,000 LB - For Tri-Axle Groups Only		
	GO250-HKANT40K-FF	48,000 LB – For Tandem Axle Groups with Hendrickson VANTRAAX HKANT 40K or ULTRAA-K UTKNT 40K Air Suspension Only		
2	HW-009-0000	250 Series Plug w/ Vent Lever		
N/A	PP-001-0004	Calibration Instructions Sticker (3.5" x 4.5")		
N/A	PF-001-0004	Tube Fitting: ¼" Tube to ¼ NPT Female Straight (Brass)		
N/A	PP-003-0016	Instruction Manual: 250 Series		


#### 250-LM



#### REPLACEMENT PARTS


Reference #	Part Number	Part Description		
	GO250-16KG-LM	16,000 KG – For Single Axle Groups Only		
	GO250-25KG-LM	25,000 KG – For Tandem Axle Groups Only		
	GO250-30KG-LM	30,000 KG – For Tri-Axle Groups Only		
1	GO250-30-LM	30,000 LB - For Single Axle Groups Only		
1	GO250-54-LM	54,000 LB - For Tandem Axle Groups Only		
	GO250-64-LM	64,000 LB - For Tri-Axle Groups Only		
	GO250-HKANT40K-LM	48,000 LB - For Tandem Axle Groups with Hendrickson VANTRAAX HKANT 40K or ULTRAA-K UTKNT 40K Air Suspension Only		
2	HW-009-0000	250 Series Plug w/ Vent Lever		
N/A	PP-001-0004	Calibration Instructions Sticker (3.5" x 4.5")		
N/A	PF-001-0004	Tube Fitting: ¼" Tube to ¼ NPT Female Straight (Brass)		
N/A PP-003-0016		Instruction Manual: 250 Series		

#### 301-QDK



REPLACEMENT PARTS				PARTS KITS		
Reference #	Part Number	Part Description	Quantity	HB-002-0004		
1	PN-004-0200 Air Hose Assembly: ¼" Polyurethane, Self-Storing, ¼" Inner Diameter x ¼-NPT Male, 360 Swivel Both Ends, 25 Feet Long, 125 PSI		1			
2	PN-004-0003	Air Line: ¼" x 0.17" Black Polyethylene, 80 Ft	1			
3	HW-999-0207	Zip Tie: 7" Black Nylon	40			
4	PF-001-0015	Terminal Bolt: ¼ NPT Female to ¼ NPT Female (Brass) 31/32" Long	2	X		
5	PF-001-0016	Industrial Manual Connection Coupler: ¼" Coupler to ¼ NPT Male	1	X		
6	PF-001-0003	Bushing: 3/8 NPT Male to ¼ NPT Female (Brass)	1	X		
7	PF-001-0017	Industrial Manual Connection Nipple: ¼" Nipple to ¼ NPT Female	1	x		
8	PF-001-0013	Tube Fitting: ¼" Tube to ¼ NPT Male Straight (Brass)	3	X		
9	PF-001-0011	Street Tee Fitting: 3/8 NPT (Brass)	1	x		
10	PF-001-0002	Street Tee Fitting: ¼ NPT (Brass)	1	х		
N/A	PP-003-0009	Instruction Manual: 301-QDK	1			

#### 310-PP




#### REPLACEMENT PARTS

#### REPLACEMENT PARTS KITS

Reference #	Part Number	Description	QTY	310-XX-01	909-BR	909-310	919-PP	HB-001-0000
	310-16KG-GO	Gauge: 3.5" - 16,000 KG (Single Axle)	1	Х				
	310-25KG-GO	Gauge: 3.5" - 25,000 KG (Tandem Axle)	1	Х				
	310-30KG-GO	Gauge: 3.5" - 30,000 KG (Tri Axle)	1	X				
	B310-30KG-GO	Gauge: 3.5" - 30,000 KG (Tri Axle) (Large Dia. Air Bag)	1	X				
1	310-30-GO	Gauge: 3.5" - 30,000 LB (Single Axle)	1	Х				
	310-54-GO	Gauge: 3.5" - 54,000 LB (Tandem Axle)	1	X				
	310-80-GO	Gauge: 3.5" - 80,000 LB (Single Axle)	1	X				
	310-HKANT40K-GO	Gauge: 3.5" - 48,000 LB – For Tandem Axle Groups with Hendrickson VANTRAAX HKANT 40K or ULTRAA-K UTKNT 40K Air Suspension Only	1	×				
2	PN-001-0000	Push-Pull Valve (Single Inlet Port)	1	X			х	
3	HW-001-0808	Screw: #8 x 1 ¾" Oval Head Phillips Tapping (Stainless Steel)	2	х			х	
4	PF-001-0010	Reducer Fitting Adaptor: ¼-NPT Female to 1/8-NPT Male (Brass)	1	X			X	
5	HW-004-1401	Insert Lock Nut: ¼-20 Nylon (18-8 Stainless Steel)	4		X			X
6	HW-003-0001	Flat Washer: ¼" (18-8 Stainless Steel)	4		×			X
7	HW-002-0002	Hex Cap Screw: ¼-20 x ¾ (18-8 Stainless Steel)	4		Х			X
8	HW-004-3801	Insert Lock Nut: %-16 Nylon (18-8 Stainless Steel)	2		X			X
9	HW-003-0003	Flat Washer: %" (18-8 Stainless Steel)	2		Х			Х
10	HW-002-0003	Hex Cap Screw: %-16 x 1 (18-8 Stainless Steel)	2		Х			х
11	HW-010-0001	Mounting Bracket	1		Х			
12	EN-001-0004	Exterior Gauge Enclosure Box	1			Х		
13	PP-001-0003	Calibration Instructions Sticker	1			Х		
14	PP-001-0002	Right Weigh Logo Sticker	1			Х		
N/A	PP-003-0000	Instruction Manual: 310-PP	1					

#### 310-M3




#### REPLACEMENT PARTS REPLACEMENT PARTS KITS

Reference #	Part Number	Part Description	QTY	909-BR	909-310	919-M3	HB-001-0000
	310-16KG-GO	Gauge: 3.5" - 16,000 KG (Single Axle)	1				
	310-25KG-GO	Gauge: 3.5" - 25,000 KG (Tandem Axle)	1				
	310-30KG-GO	Gauge: 3.5" - 30,000 KG (Tri Axle)	1				
	B 310-30KG-GO	Gauge: 3.5" - 30,000 KG (Tri Axle) (Large Dia. Air Bag)	1				
1	310-30-GO	Gauge: 3.5" - 30,000 LB (Single Axle)	1				
	310-54-GO	Gauge: 3.5" - 54,000 LB (Tandem Axle)	1				
	310-80-GO	Gauge: 3.5" - 80,000 LB (Single Axle)	1				
	310-HKANT40K-GO	Gauge: 3.5" - 48,000 LB (Tandem Axle) (Hendrickson VAN- TRAAX, INTRAAX, HKANT40K)	1				
2	PN-001-0102	Push-Pull Valve (Dual Inlet Port)	1			Х	
3	HW-001-0808	Screw: #8 x 1 ¾" Oval Head Phillips Tapping (Stainless Steel)	2			Х	
4	PF-001-0010	Reducer Fitting Adaptor: ¼-NPT Female to ¼-NPT Male (Brass)	2			Х	
5	HW-004-1401	Insert Lock Nut: ¼-20 Nylon (18-8 Stainless Steel)	4	Х			Х
6	HW-003-0001	Flat Washer: ¼" (18-8 Stainless Steel)	4	X			X
7	HW-002-0002	Hex Cap Screw: ¼-20 x ¾ (18-8 Stainless Steel)	4	х			Х
8	HW-004-3801	Insert Lock Nut: %-16 Nylon (18-8 Stainless Steel)	2	х			Х
9	HW-003-0003	Flat Washer: 3/8" (18-8 Stainless Steel)	2	х			Х
10	HW-002-0003	Hex Cap Screw: 3/8-16 x 1 (18-8 Stainless Steel)	2	X			
11	HW-010-0001	Mounting Bracket	1	Х			
12	EN-001-0004	Exterior Gauge Enclosure Box	1		Х		
13	PP-001-0003	Calibration Instructions Sticker	1		Х		
14	PP-001-0002	Right Weigh Logo Sticker	1		Х		
N/A	PF-001-0008	Brass Adaptor: ¼-NPT Female to ¼-NPT Male	1				
N/A	PP-003-0013	Instruction Manual: 310-M3	1				

©Right Weigh, Inc. 2021

#### 400-54-RFB




#### REPLACEMENT PARTS LIST REPLACEMENT PART KITS Reference # 909-BR HB-001-0000 Description 1 400-54-RF Gauge: 4" - 54,000LB (Tandem Axle) Glycerin Filled 1 HW-009-0006 400 Series Rear Flange Gasket 3 3 HW-002-0004 Hex Cap Screw: 6-32 x ½" (Stainless Steel) HW-004-6321 Insert Lock Nut: 6-32 Nylon (18-8 Stainless Steel) 5 HW-004-1401 Insert Lock Nut: 1/4-20 Nylon (18-8 Stainless Steel) 4 Х Χ Χ Χ 6 HW-003-0001 Flat Washer: 1/4" (18-8 Stainless Steel) 4 7 HW-002-0002 Hex Cap Screw: ¼-20 x ¾ (18-8 Stainless Steel) 4 Χ Χ Χ Χ 8 HW-004-3801 Insert Lock Nut: 3/8-16 Nylon (18-8 Stainless Steel) 2 9 HW-003-0003 Flat Washer: 3/8" (18-8 Stainless Steel) 2 10 HW-002-0003 Hex Cap Screw: 3/8-16 x 1 (18-8 Stainless Steel) 2 Χ Χ HW-010-0001 1 11 Mounting Bracket 12 EN-001-0011 Exterior Gauge Enclosure Box PP-001-0003 13 Calibration Instructions Sticker 1 14 PP-001-0002 Right Weigh Logo Sticker 1 PF-001-0004 N/A Straight Brass Fitting Connector: $\frac{1}{4}$ " Tube to $\frac{1}{4}$ -NPT Female 1

REPLACEMENT PARTS KIT

Χ

1

#### EL-004-0049



#### RTSK-01


REPLACEMENT PARTS

HW-004-0004

PP-003-0032

4

N/A




#### Reference Parts Number Quantity HB-001-0006 Push-to-Connect Fitting: ¼" Tube to 10-32 Male Elbow 1 PF-002-0002 1 Swivel (Nickel Pated Brass) 2 HW-002-0005 Hex Cap Screw: 5/16-18 x 1" (18-8 Stainless Steel) 2 Χ 3 HW-003-0007 Flat Washer: 5/16" (18-8 Stainless Steel) Χ


©Right Weigh, Inc. 2021 71


Nylon Insert Lock Nut: 5/16-18 (18-8 Stainless Steel)


Instruction Manual: RTSK-01


# PLUMBING DIAGRAMS
















#### 301-QDK







## Warranty

Right Weigh is committed to providing quality products that function as intended, and we always stand behind our workmanship. Our industry-leading warranty is our best effort to express this commitment. Products manufactured or sold by Right Weigh, Inc. are warrantied to be free from significant defects in material and workmanship 3 years from date of purchase. During this time, and within the boundaries set forth in this warranty statement, Right Weigh, Inc. will, at its sole discretion, correct the product problem or replace the product.

This warranty shall not apply to product problems resulting from: (1) Improper application, installation, incorrect wiring, or operation outside of the approved specifications of the product. (2) Accidents, faulty suspension parts or power surges (3) Inadequate maintenance or preparation by the buyer or user (4) Abuse, misuse, or unauthorized modification. (5) Acts of God, lightning strike, floods, fire, earthquake, etc.

Right Weigh, Inc. assumes no responsibility or liability for any loss or damages resulting from use of Right Weigh, Inc. products.

In no event shall Right Weigh, Inc. be liable for direct, indirect, special, incidental or consequential damages (including loss of profits or loss of time) resulting from the performance of a Right Weigh, Inc. product. In all cases, Right Weigh, Inc. liability will be limited to the original cost of the product in question. Right Weigh, Inc. reserves the right to make improvements in design, construction, and appearance of products without notice.


### Return Authorization and Credit Policy

Before returning any product, please obtain a Return Merchandise Authorization number (RMA#) by calling Customer Service at (503) 628-0838 or emailing rwls@ rwls.com. Include the RMA# and information regarding the reason for the return with the returned product. Shipping costs for return must be prepaid by the customer. For your protection, items must be carefully packed to prevent damage in shipment and insured against possible damage or loss. Right Weigh, Inc. will not be responsible for damage resulting from careless or insufficient packing or loss in transit.

An RMA# must be obtained by the original purchaser before any product can be returned for credit. Only new, unused products may be returned. Installed, used, damaged, modified or customized products cannot be returned for credit. Credit will be issued to the original purchaser after evaluation by Right Weigh, Inc.

#### **Repairs & Replacements**

An RMA# must be obtained before any product can be returned. Right Weigh, Inc. will evaluate returned products at no charge. If Right Weigh, Inc. determines that the returned product is under warranty, it will repair the product or parts thereof at no charge, or, if unrepairable, replace it with the same or functionally equivalent product whenever possible. Right Weigh, Inc. will return the product at its expense via a shipping method (carrier to be at sole discretion of Right Weigh, Inc.) equal to or faster than the method used by the customer. Products or parts thereof not covered by warranty will be repaired or replaced at customer expense upon authorization by the customer. Right Weigh, Inc. will return the repaired product at customer expense via a shipping method (carrier to be at sole discretion of Right Weigh, Inc.) equal to or faster than the method used by the customer.



With our app, it's easier than ever to monitor your load weight at any time on your smartphone.





Right Weigh, Inc. 8120 NE Mauzey Court Hillsboro, OR 97124 Phone: (503) 628-0838 Toll Free: (888) 818-2058

Fax: (503) 628-0863

Email: rwls@rwls.com

www.rwls.com

Follow us:













(503) 628-0838 | 888.818.2058 (U.S.) | rwls@rwls.com | www.rwls.com