

Installation and Operation Instructions ED3801 and ED3802 Directional LED

IMPORTANT! Read all instructions before installing and using. Installer: This manual must be delivered to the end user.

WARNING!

Failure to install or use this product according to manufacturer's recommendations may result in property damage, serious injury, and/

Do not install and/or operate this safety product unless you have read and understood the safety information contained in this manual.

- 1. Proper installation combined with operator training in the use, care, and maintenance of emergency warning devices are essential to ensure the safety of emergency personnel and the public.
- 2. Emergency warning devices often require high electrical voltages and/or currents. Exercise caution when working with live electrical connections.
- 3. This product must be properly grounded. Inadequate grounding and/or shorting of electrical connections can cause high current arcing, which can cause personal injury and/or severe vehicle damage, including fire.
- 4. Proper placement and installation is vital to the performance of this warning device. Install this product so that output performance of the system is maximized and the controls are placed within convenient reach of the operator so that they can operate the system without losing eye contact with the roadway.
- 5. Do not install this product or route any wires in the deployment area of an air bag. Equipment mounted or located in an air bag deployment area may reduce the effectiveness of the air bag or become a projectile that could cause serious personal injury or death. Refer to the vehicle owner's manual for the air bag deployment area. It is the responsibility of the user/operator to determine a suitable mounting location ensuring the safety of all passengers inside the vehicle particularly avoiding areas of potential head impact.
- 6. It is the responsibility of the vehicle operator to ensure daily that all features of this product work correctly. In use, the vehicle operator should ensure the projection of the warning signal is not blocked by vehicle components (i.e., open trunks or compartment doors), people, vehicles or other obstructions.
- 7. The use of this or any other warning device does not ensure all drivers can or will observe or react to an emergency warning signal. Never take the right-of-way for granted. It is the vehicle operator's responsibility to be sure they can proceed safely before entering an intersection, drive against traffic, respond at a high rate of speed, or walk on or around traffic lanes.
- 8. This equipment is intended for use by authorized personnel only. The user is responsible for understanding and obeying all laws regarding emergency warning devices. Therefore, the user should check all applicable city, state, and federal laws and regulations. The manufacturer assumes no liability for any loss resulting from the use of this warning device.

Specifications:

Input Voltage:		12 - 24VDC
Work Current:	ED3801X	0.8A @ 12VDC
	ED3802XX	0.8A @ 12VDC
	ED3802XXX	0.9A @ 12VDC
Temp. Range:		-40°C to 65°C
		-40°F to 149°F

IMPORTANT! This unit is a safety device and it must be connected to its own separate, fused power point to assure its continued operation should any other electrical accessory fail.



CAUTION!

When drilling into any vehicle surface, make sure that the area is free from any electrical wires, fuel lines, vehicle upholstery, etc. that could be damaged.

Note: It is recommended to isolate wires/blunt wires that were cut or not used.




Figure 1

Wiring Instructions:

ED3801X

RED Wire: Positive (need to add 2A fuse) BLACK Wire: Negative BLUE Wire: Pattern Select to Negative YELLOW Wire: Synchronized Function (Up to 8 units can be Synchronized)

ED3802XX

RED Wire:	Positive, Colors 1 & 3 (need to add 2A fuse)				
WHITE Wire:	Positive, Colors 2 & 4 (need to add 2A fuse)				
BLACK Wire:	Negative				
BLUE Wire:	Pattern Select to Negative				
YELLOW Wire:	Synchronized Function				
(Up to 8 units can be Synchronized)					

ED3802XXX

RED Wire:	Positive, Group 1 (need to add 2A fuse)				
WHITE Wire:	Positive, Group 2 (need to add 2A fuse)				
RED & WHITE Wire:	Positive, Group 3 (need to add 2A fuse)				
BLACK Wire:	Negative				
BLUE Wire:	Pattern Select to Negative				
YELLOW Wire:	Synchronized Function				
GREEN Wire:	Mode Select				
(Up to 8 units can be Synchronized)					

Flash Patterns:

Phase Operation:

Phase 1 (Ph1) flashes simultaneously with Ph1 Phase 2 (Ph2) flashes simultaneously with Ph2 Ph1 alternates with Ph2 (Up to 8 units can be Synchronized)

Apply BLUE TO BLACK wire:

-Less than 1 sec. for next pattern -Between 1-3 sec for previous pattern -Between 3-5 sec. for factory default pattern -More than 5 sec. for pattern 12 (ED3802XX, ED3802XXX) and pattern 13 (ED3801X)

ED3801X Flash Pattern Chart

PATTERN	Flash	sim. Phase1	sim. Phase2	Alt.
1	Single Flash 75FPM	S1,C	S1,C	N/A
2	Single Flash 120FPM	S1,E1	S1,E1	N/A
3	Double Flash 75FPM	S1	S1	N/A
4	Double Flash 120FPM	S1,E1	S1,E1	N/A
5	Quad Flash 75FPM	R/B/A for S1,W for S2	R/B/A for S1,W for S2	N/A
6	Quad Flash 150FPM	R/B/A for S1,W for S2	R/B/A for S1,W for S2	N/A
7	Triple 75FPM	S1	S1	N/A
8	Quint Flash 150FPM	R/B/A for S1,W for S2	R/B/A for S1,W for S2	N/A
9	Steady - Single	N/A		
10	Steady Burn	N/A		
11	Modulation	N/A		
12	2 Double Flash,2 Triple Alt.	N/A		
13	4 Single Flash ,2 Quad Flash Alt.	N/A		

ED3802XXX Flash Pattern Chart

		Group 1(Red line)									
				up 2(White	/						
PATTERN GROUP			Group 3	Red & Wh				FLASH PATTERN	SYNC.	COMPLIES WITH	
GROOT	Mode1 Color1	Mode2 Color2	Mode3 Color3	Mode4 Color 1 & 2	Mode5 Color 1 & 3	Mode6 Color 2 & 3	Mode7 Color 1&2&3				
1	1-Default	1-Default	1-Default	1-Default	1-Default	1-Default	1-Default	Single 75FPM Ph1	yes	R/B for S1-A/W for S2	
1	2	2	2	2	2	2	2	Single 75FPM Ph2	yes	R/B for S1-A/W for S2	
2	3	3	3	3	3	3	3	Single 120FPM Ph1	yes	R/B/A for S1-W for S2,E1	
2	4	4	4	4	4	4	4	Single 120FPM Ph2	yes	R/B/A for S1-W for S2,E1	
3	5	5	5	5	5	5	5	Single 375FPM Ph1	yes		
5	6	6	6	6	6	6	6	Single 375FPM Ph2	yes		
4	7	7	7	7	7	7	7	Double 75FPM Ph1	yes	R/B/A for S1-W for S2	
4	8	8	8	8	8	8	8	Double 75FPM Ph2	yes	R/B/A for S1-W for S2	
5	9	9	9	9	9	9	9	Double 120FPM Ph1	yes	R/B for S1-A/W for S2,E1	
5	10	10	10	10	10	10	10	Double 120FPM Ph2	yes	R/B for S1-A/W for S2,E1	
6	11	11	11	11	11	11	11	Triple 75FPM Ph1	yes	R/B/A for S1-W for S2,R/B for C	
0	12	12	12	12	12	12	12	Triple 75FPM Ph2	yes	R/B/A for S1-W for S2,R/B for C	
7	13	13	13	13	13	13	13	Quad 75FPM Ph1	yes	R/B for S1-A/W for S2	
'	14	14	14	14	14	14	14	Quad 75FPM Ph2	yes	R/B for S1-A/W for S2	
8	15	15	15	15	15	15	15	Quad 150FPM Ph1	yes	R/B for S1-A/W for S2,E1	
0	16	16	16	16	16	16	16	Quad 150FPM Ph2	yes	R/B for S1-A/W for S2,E1	
9	17	17	17					CA T13 Single Flash 75FPM	no	S,R/B for C	
10	18	18	18					CA T13 Double Flash 75FPM	no	S,R/B for C	
11	19	19	19					NFPA-Quad Flash 75FPM	no	S,R/B for C	
12	20	20	20					ModuFlash sim.	no		
13	21	21	21					2 Double Flash,2 Quad Flash	no		
14	22	22	22					4 Single Flash ,2 Triple Flash	no		
15	23	23	23					Autorun	no		
16	24	24	24					steady burn	no		

ED3802XX Flash Pattern Chart

Pattern	LED Color 1 & Color 3 Red line	LED Color 2 & Color 4 White line	LED Color 1 & Color 3 LED Color 2 & Color 4 Red & White line	PATTERNS	SYNC.	COMPLIES WITH
	1-Default		1	SAE/T13 SAE/T13 Single 75FPM Ph1 Color 1 Synchronous Color 3	yes	\$1,C
	2		2	SAE/T13 SAE/T13 Single 75FPM Ph2 Color 1 Synchronous Color 3	yes	S1,C
			3	SAE/T13 Single 75FPM Ph1 Color 1 Alternately Color 4	yes	
			4	SAE/T13 Single 75FPM Ph2 Color 1 Alternately Color 4	yes	
1		1-Default	5	SAE/T13 Single 75FPM Ph1 Color 2 Synchronous Color 4	yes	\$1,C
		2	6	SAE/T13 Single 75FPM Ph2 Color 2 Synchronous Color 4	yes	\$1,C
	3	3	7	SAE/T13 Single 38FPM Ph1(Color 1 Synchronous Color 3) Alternately (Color 2 Synchronous Color 4)	yes	
	4	4	8	SAE/T13 Single 38FPM Ph2(Color 1 Synchronous Color 3) Alternately (Color 2 Synchronous Color 4)	yes	
	5	5	9	SAE/T13 Single 38FPM (Color 1 Alternately Color 2) Alternately (Color 3 Alternately Color 4)	yes	
	6		10	Single 375FPMFPM Ph1 Color 1 Synchronous Color 3	yes	
	7		11	Single 375FPMFPM Ph2 Color 1 Synchronous Color 3	yes	
			12	Single 375FPMFPM Ph1 Color 1 Alternately Color 4	yes	
			13	Single 375FPMFPM Ph2 Color 1 Alternately Color 4	yes	
2		6	14	Single 375FPMFPM Ph1 Color 2 Synchronous Color 4	yes	
2		7	15	Single 375FPMFPM Ph2 Color 2 Synchronous Color 4		
	8	8	15		yes	
				Single 187FPMFPM Ph1 (Color 1 Synchronous Color 3) Alternately (Color 2 Synchronous Color 4)	yes	
	9	9	17	Single 187FPMFPM Ph2 (Color 1 Synchronous Color 3) Alternately (Color 2 Synchronous Color 4)	yes	
	10	10	18	Single 187FPMFPM (Color 1 Alternately Color 2) Alternately (Color 3 Alternately Color 4)	yes	
	11		19	SAE/T13 Double 75FPM Ph1 Color 1 Synchronous Color 3	yes	S1
	12		20	SAE/T13 Double 75FPM Ph2 Color 1 Synchronous Color 3	yes	S1
			21	SAE/T13 Double 75FPM Ph1 Color 1 Alternately Color 4	yes	
			22	SAE/T13 Double 75FPM Ph2 Color 1 Alternately Color 4	yes	
3		11	23	SAE/T13 Double 75FPM Ph1 Color 2 Synchronous Color 4	yes	S1
		12	24	SAE/T13 Double 75FPM Ph2 Color 2 Synchronous Color 4	yes	S1
	13	13	25	SAE/T13 Double 38FPM Ph1 (Color 1 Synchronous Color 3) Alternately (Color 2 Synchronous Color 4)	yes	
	14	14	26	SAE/T13 Double 38FPM Ph2 (Color 1 Synchronous Color 3) Alternately (Color 2 Synchronous Color 4)	yes	
	15	15	27	SAE/T13 Double 38FPM (Color 1 Alternately Color 2) Alternately (Color 3 Alternately Color 4)	yes	
	16	15	28	ECER65/SAE Double 120FPM Ph1 Color 1 Synchronous Color 3	yes	\$1,E1
	17		29	ECER65/SAE Double 120FPM Ph2 Color 1 Synchronous Color 3	-	S1,E1
	17		30		yes	31,11
				ECER65/SAE Double 120FPM Ph1 Color 1 Alternately Color 4	yes	
			31	ECER65/SAE Double 120FPM Ph2 Color 1 Alternately Color 4	yes	04 F4
4		16	32	ECER65/SAE Double 120FPM Ph1 Color 2 Synchronous Color 4	yes	\$1,E1
		17	33	ECER65/SAE Double 120FPM Ph2 Color 2 Synchronous Color 4	yes	\$1,E1
	18	18	34	ECER65/SAE Double 60FPM Ph1 (Color 1 Synchronous Color 3) Alternately (Color 2 Synchronous Color 4)	yes	
	19	19	35	ECER65/SAE Double 60FPM Ph2 (Color 1 Synchronous Color 3) Alternately (Color 2 Synchronous Color 4)	yes	
	20	20	36	ECER65/SAE Double 60FPM (Color 1 Alternately Color 2) Alternately (Color 3 Alternately Color 4)	yes	
	21		37	SAE/T13 Triple 75FPM Ph1 Color 1 Synchronous Color 3	yes	R/B/A for S1,W for S2
	22		38 39	SAE/T13 Triple 75FPM Ph2 Color 1 Synchronous Color 3 SAE/T13 Triple 75FPM Ph1 Color 1 Alternately Color 4	yes	R/B/A for S1,W for S2
			40	SAE/T13 Triple 75FPM Ph2 Color 1 Alternately Color 4	yes yes	
5		21	41	SAE/T13 Triple 75FPM Ph1 Color 2 Synchronous Color 4	yes	R/B/A for S1,W for S2
5		22	42	SAE/T13 Triple 75FPM Ph2 Color 2 Synchronous Color 4	yes	R/B/A for S1,W for S2
	23	23	43	SAE/T13 Triple 38FPM Ph1 (Color 1 Synchronous Color 3) Alternately (Color 2 Synchronous Color 4)	yes	
	24	24	44	SAE/T13 Triple 38FPM Ph2 (Color 1 Synchronous Color 3) Alternately (Color 2 Synchronous Color 4)	yes	
	25	25	45	SAE/T13 Triple 38FPM (Color 1 Alternately Color 2) Alternately (Color 3 Alternately Color 4)	yes	
	26		46	SAE/T13 Quad 75FPM Ph1 Color 1 Synchronous Color 3	yes	R/B/A for S1,W for S2
	27		47	SAE/T13 Quad 75FPM Ph2 Color 1 Synchronous Color 3 SAE/T13 Quad 75FPM Ph1 Color 1 Alternately Color 4	yes	R/B/A for S1,W for S2
			48 49	SAE/113 Quad /SFPM Ph1 Color 1 Alternately Color 4 SAE/T13 Quad 75FPM Ph2 Color 1 Alternately Color 4	yes yes	
6		26	50	SAE/T13 Quad 75FPM Ph1 Color 2 Synchronous Color 4	yes	R/B/A for S1,W for S2
5		20	50	SAE/T13 Quad 75FPM Ph2 Color 2 Synchronous Color 4	yes	R/B/A for S1,W for S2
	28	28	52-Default	SAE/T13 Quad 38FPM Ph1 (Color 1 Synchronous Color 3) Alternately (Color 2 Synchronous Color 4)	yes	
	29	29	53	SAE/T13 Quad 38FPM Ph2 (Color 1 Synchronous Color 3) Alternately (Color 2 Synchronous Color 4)	yes	
	30	30	54	SAE/T13 Quad 38FPM (Color 1 Alternately Color 2) Alternately (Color 3 Alternately Color 4)	yes	
	31		55	ECER65/SAE Quad 120FPM Ph1 Color 1 Synchronous Color 3	yes	R/B/A for S1,W for S2
	32		56 57	ECER65/SAE Quad 120FPM Ph2 Color 1 Synchronous Color 3	yes	R/B/A for S1,W for S2
			57	ECER65/SAE Quad 60FPM Ph1 Color 1 Alternately Color 4 ECER65/SAE Quad 120FPM Ph2 Color 1 Alternately Color 4	yes yes	
7		31	59	ECER65/SAE Quad 120FPM Ph2 Color 1 Alternately Color 4	yes	R/B/A for S1,W for S2
/		32	60	ECER65/SAE Quad 120FPM Ph2 Color 2 Synchronous Color 4	yes	R/B/A for S1,W for S2
	33	33	61	ECER65/SAE Quad 60FPM Ph1 (Color 1 Synchronous Color 3) Alternately (Color 2 Synchronous Color 4)	yes	,
	34	34	62	ECER65/SAE Quad 60FPM Ph2 (Color 1 Synchronous Color 3) Alternately (Color 2 Synchronous Color 4)	yes	
	35	35	63	ECER65/SAE Quad 60FPM (Color 1 Alternately Color 2) Alternately (Color 3 Alternately Color 4)	yes	
8			64	Modulation (Color 1 Synchronous Color 3) Alternately (Color 2 Synchronous Color 4)	no	
9			65	2 Double, 2 Quad (Color 1 Synchronous Color 3) Alternately (Color 2 Synchronous Color 4)	no	L
10			66 67	4 Single,2 Triple (Color 1 Synchronous Color 3) Alternately (Color 2 Synchronous Color 4) 1Doube 1Triple 1Quad (Color 1 Synchronous Color 3) Alternately (Color 2 Synchronous Color 4)	no	
	36		68	Steady burn-Color 1 & 3	no	
12	h	36	69	Steady burn-Color 2 & 4	no	

Troubleshooting:

The ED3801X, ED3802XX, and ED3802XXX series are factory tested and approved. If any of the functions of the device fail to operate, please check the following:

PROBLEM	QUESTION		CAUSE	SOLUTION	
Product does not	en functioning	Are LEDs	Yes	a. Plug is loose or disconnected.	a. Reconnect plug.
function when		ioning	b. Poor ground connection	b. Reconnect ground.	
turned on properly?		No	a. Power has been disconnected.	a. Check connections at the battery and plug.	

Warranty:

Manufacturer Limited Warranty Policy:

Manufacturer warrants that on the date of purchase this product will conform to Manufacturer's specifications for this product (which are available from the Manufacturer upon request). This Limited Warranty extends for Sixty (60) months from the date of purchase.

DAMAGE TO PARTS OR PRODUCTS RESULTING FROM TAMPERING, ACCIDENT, ABUSE, MISUSE, NEGLIGENCE, UNAPPROVED MODIFICA-TIONS, FIRE OR OTHER HAZARD; IMPROPER INSTALLATION OR OPERATION; OR NOT BEING MAINTAINED IN ACCORDANCE WITH THE MAINTENANCE PROCEDURES SET FORTH IN MANUFACTURER'S INSTALLATION AND OPERATING INSTRUCTIONS VOIDS THIS LIMITED WAR-RANTY.

Exclusion of Other Warranties:

MANUFACTURER MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED. THE IMPLIED WARRANTIES FOR MERCHANTABILITY, QUALITY OR FITNESS FOR A PARTICULAR PURPOSE, OR ARISING FROM A COURSE OF DEALING, USAGE OR TRADE PRACTICE ARE HEREBY EX-CLUDED AND SHALL NOT APPLY TO THE PRODUCT AND ARE HEREBY DISCLAIMED, EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW. ORAL STATEMENTS OR REPRESENTATIONS ABOUT THE PRODUCT DO NOT CONSTITUTE WARRANTIES.

Remedies and Limitation of Liability:

MANUFACTURER'S SOLE LIABILITY AND BUYER'S EXCLUSIVE REMEDY IN CONTRACT, TORT (INCLUDING NEGLIGENCE), OR UNDER ANY OTHER THEORY AGAINST MANUFACTURER REGARDING THE PRODUCT AND ITS USE SHALL BE, AT MANUFACTURER'S DISCRETION, THE REPLACEMENT OR REPAIR OF THE PRODUCT, OR THE REFUND OF THE PURCHASE PRICE PAID BY BUYER FOR NON-CONFORMING PROD-UCT. IN NO EVENT SHALL MANUFACTURER'S LIABILITY ARISING OUT OF THIS LIMITED WARRANTY OR ANY OTHER CLAIM RELATED TO THE MANUFACTURER'S PRODUCTS EXCEED THE AMOUNT PAID FOR THE PRODUCT BY BUYER AT THE TIME OF THE ORIGINAL PURCHASE. IN NO EVENT SHALL MANUFACTURER BE LIABLE FOR LOST PROFITS, THE COST OF SUBSTITUTE EQUIPMENT OR LABOR, PROPERTY DAMAGE, OR OTHER SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES BASED UPON ANY CLAIM FOR BREACH OF CONTRACT, IM-PROPER INSTALLATION, NEGLIGENCE, OR OTHER CLAIM, EVEN IF MANUFACTURER OR A MANUFACTURER'S REPRESENTATIVE HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. MANUFACTURER SHALL HAVE NO FURTHER OBLIGATION OR LIABILITY WITH RESPECT TO THE PRODUCT OR ITS SALE, OPERATION AND USE, AND MANUFACTURER NEITHER ASSUMES NOR AUTHORIZES THE ASSUMPTION OF ANY OTHER OBLIGATION OR LIABILITY IN CONNECTION WITH SUCH PRODUCT.

This Limited Warranty defines specific legal rights. You may have other legal rights which vary from jurisdiction to jurisdiction. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages.



833 West Diamond St, Boise, Idaho 83705 **Customer Service** USA 800-635-5900 UK +44 (0)113 237 5340 | AUS +61 (0)3 63322444 **ECCOESG.**com

An ECCO SAFETY GROUP™ Brand ECCOSAFETYGROUP.com