

EXTREME CAM PRODUCT GUIDE

2022





11" 28-SPLINE S-CAM FULL KITS	. 4
11" 10-SPLINE S-CAM FULL KITS	. 6
11" REPLACEMENT TUBE KITS	. 8
11" REPLACEMENT TUBES	. 9
15" 28-SPLINE S-CAM FULL KITS	10
15" REPLACEMENT TUBE KITS	. 1 1
16" 28-SPLINE S-CAM FULL KITS	12
16" REPLACEMENT TUBE KITS	13
17" 28-SPLINE S-CAM FULL KITS	14
17" REPLACEMENT TUBE KITS	15
18" 28-SPLINE S-CAM FULL KITS	16
18" REPLACEMENT TUBE KITS	17
19" 28-SPLINE S-CAM FULL KITS	18
19" REPLACEMENT TUBE KITS	19
20" 28-SPLINE S-CAM FULL KITS	. 20
20" REPLACEMENT TUBE KITS	. 21
21" 28-SPLINE S-CAM FULL KITS	. 22
21" REPLACEMENT TUBE KITS	. 23
22" 28-SPLINE S-CAM FULL KITS	. 24
22" REPLACEMENT TUBE KITS	. 25
23" 28-SPLINE S-CAM FULL KITS	. 26
23" REPLACEMENT TUBE KITS	27
24" 28-SPLINE S-CAM FULL KITS	28
24" REPLACEMENT TUBE KITS	29
25" 28-SPLINE S-CAM FULL KITS	30
25" REPLACEMENT TUBE KITS	31
26" 28-SPLINE S-CAM FULL KITS	32
26" REPLACEMENT TUBE KITS	33
30" 28-SPLINE S-CAM FULL KITS	34
30" REPLACEMENT TUBE KITS	35
EXTREME S-CAMS – 28 SPLINE	36
EXTREME S-CAMS - 10 SPLINE	36
EXTREME CAM ACCESSORIES	38





EXTREME CAM ALL-INCLUSIVE KITS CONTAIN EVERYTHING YOU NEED TO CONVERT ANY TRAILER TO A FULLY ENCLOSED CAM TUBE SYSTEM





WHY EXTREME CAMS?

The Extreme Cam is specifically engineered to extend the life of your brakes. Our customers tell us they are getting up to five times the life out of their s-cams and cam bushings and are significantly increasing the life of their brakes and drums. Each all-inclusive kit contains everything that you need to convert any trailer to the



Extreme Cam s-cam / bushing system. You'll receive an Extreme S-Cam, Extreme Cam enclosure tube & cam bushing, a mounting bracket kit, and washer/spacer kit. Ease of installation is key, so the Extreme Cam is a complete bolt-on solution with no welding required.

HOW ARE EXTREME CAMS SUPERIOR?

We manufacture Extreme Cam kits in our in-house production facility. It all starts with using American-made steel and precision manufacturing processes. We use an ISO 9000 inspired quality management system to ensure we are delivering bushings with the tightest tolerances in the industry. Our bushings are made with a proprietary combination of materials and production processes that we guarantee will outperform the competition. Our Extreme Cam tubes are built with .125" wall DOM steel tubing that is measurably stronger than the 16-gauge material used by our competitors. We also have aggressive procedures to fight corrosion from the start. First, we powder coat every Extreme Cam enclosure tube. Next, we use anti-corrosion bushings with 5 large grease channels to ensure your s-cam stays lubricated. Then we install our specially designed double lip seals to keep contaminants from infiltrating your cam tubes. Finally, we install a pressure relief valve that lets excess grease out without compromising the integrity of the seals.

www.extremebrake.com





11" 28-SPLINE S-CAM FULL KITS

Extreme Cam left-hand and right-hand (-L and -R) kits include the s-cam, enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set.

- C1311A-L Extreme S-Cam Bushing Kit (11-1/32" S-Cam, 2-1/8" Bore, Left-Hand)
- C1311O-L Extreme S-Cam Bushing Kit (11-1/32" S-Cam, **Oversized** 2.16" Bore, Left-Hand)
- C1411A-L Extreme S-Cam Bushing Kit (11-1/32" S-Cam, **Double Oversized** 2-3/16" Bore, Left-Hand)



- C1311A-R Extreme S-Cam Bushing Kit (11-1/32" S-Cam, 2-1/8" Bore, Right-Hand)
- C1311O-R Extreme S-Cam Bushing Kit (11-1/32" S-Cam, **Oversized** 2.16" Bore, Right-Hand)
- C1411A-R Extreme S-Cam Bushing Kit (11-1/32" S-Cam, **Double Oversized** 2-3/16" Bore, Right-Hand)



www.extremebrake.com





11" 28-SPLINE S-CAM FULL KITS

Extreme Cam left-hand and right-hand (-L and -R) kits include the s-cam, enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set.





C1211A-L Extreme S-Cam Bushing Kit (11-1/32" S-Cam, 2" Bore, Left-Hand)

C1211O-L Extreme S-Cam Bushing Kit (11-1/32" S-Cam, **Oversized** 2.01" Bore, Left-Hand)

C1211A-R Extreme S-Cam Bushing Kit (11-1/32" S-

Cam, 2" Bore, Right-Hand)

C1211O-R Extreme S-Cam Bushing Kit (11-1/32" S-Cam, Oversized 2.01" Bore, Right-Hand)





C1111A-L Extreme S-Cam Bushing Kit (11-1/32" S-Cam, 1-7/8" Bore, Left-Hand)

C1111A-R

Extreme S-Cam Bushing Kit (11-1/32" S-Cam, 1-7/8" Bore, Right-Hand)

www.extremebrake.com





11" 10-SPLINE S-CAM FULL KITS

Extreme Cam left-hand and right-hand (-L and -R) kits include the s-cam, enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set.

- **C0311A-L** Extreme S-Cam Bushing Kit (11-1/32" S-Cam, 2-1/8" Bore, Left-Hand)
- **C0311O-L** Extreme S-Cam Bushing Kit (11-1/32" S-Cam, **Oversized** 2.16" Bore, Left-Hand)
- **C0411A-L** Extreme S-Cam Bushing Kit (11-1/32" S-Cam, **Double Oversized** 2-3/16" Bore, Left-Hand)



- CO311A-R Extreme S-Cam Bushing Kit (11-1/32" S-Cam, 2-1/8" Bore, Right-Hand)
- C0311O-R Extreme S-Cam Bushing Kit (11-1/32" S-Cam, Oversized 2.16" Bore, Right-Hand)
- CO411A-R Extreme S-Cam Bushing Kit (11-1/32" S-Cam, Double Oversized 2-3/16" Bore, Right-Hand)







11" 10-SPLINE S-CAM FULL KITS

Extreme Cam left-hand and right-hand (-L and -R) kits include the s-cam, enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set.





CO211A-L Extreme S-Cam Bushing Kit (11-1/32" S-

Cam, 2" Bore, Left-Hand)

CO211O-L Extreme S-Cam Bushing Kit (11-1/32" S-

Cam, **Oversized** 2.01" Bore, Left-Hand)

C0211A-R

R Extreme S-Cam Bushing Kit (11-1/32" S-

Cam, 2" Bore, Right-Hand)

CO211O-R Extreme S-Cam Bushing Kit (11-1/32" S-

Cam, **Oversized** 2.01" Bore, Right-Hand)





CO111A-L Extreme S-Cam Bushing Kit (11-1/32" S-Cam, 1-7/8" Bore, Left-Hand)

C0111A-R

Extreme S-Cam Bushing Kit (11-1/32" S-Cam, 1-7/8" Bore, Right-Hand)

www.extremebrake.com





11" REPLACEMENT TUBE KITS

except the s-cam: enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set.





C1311A-RTK Extreme Cam Enclosure Tube Kit for C1411A- RTK Extreme Cam Enclosure Tube Kit for

11-1/32" S-Cam (No S-Cam Included), 2-

1/8" Bore

C1311O- RTK Extreme Cam Enclosure Tube Kit for

11-1/32" S-Cam (No S-Cam Included),

Oversized 2.01" Bore

K Extreme Cam Enclosure Tube Kit for 11-1/32" S-Cam (No S-Cam Included),

Double Oversized 2-3/16" Bore





Bore

C1211A-RTK Extreme Cam Enclosure Tube Kit for C11111A-RTK Extreme Cam Enclosure Tube Kit for 11-

11-1/32" S-Cam (No S-Cam Included),

2" Bore

C1211O-RTK Extreme Cam Enclosure Tube Kit for

11-1/32" S-Cam (No S-Cam Included),

Oversized 2.01" Bore

www.extremebrake.com



888-844-7734 | Page 8

1/32" S-Cam (No S-Cam Included), 1-7/8"



11" REPLACEMENT TUBES

Extreme Cam Tubes (-TUBE) do not include the mounting bracket set or washer/spacer set.





C1311A-TUBE Extreme Cam Enclosure Tube for 11- C1411A-TUBE Extreme Cam Enclosure Tube for 11-

1/32" S-Cam (No S-Cam Included), 2-

1/8" Bore

C1311O-TUBE Extreme Cam Enclosure Tube for 11-

1/32" S-Cam (No S-Cam Included),

Oversized 2.01" Bore

C1411A- TUBE Extreme Cam Enclosure Tube for 11-1/32" S-Cam (No S-Cam Included),

Double Oversized 2-3/16" Bore





C1211A-TUBE Extreme Cam Enclosure Tube for 11-C11111A-TUBE Extreme Cam Enclosure Tube for 11-1/32"

1/32" S-Cam (No S-Cam Included), 2"

S-Cam (No S-Cam Included), 1-7/8" Bore

Bore

C1211O-TUBE Extreme Cam Enclosure Tube for 11-

1/32" S-Cam (No S-Cam Included),

Oversized 2.01" Bore

EXTRE



15" 28-SPLINE S-CAM FULL KITS

Extreme Cam left-hand and right-hand (-L and -R) kits include the s-cam, enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set.





C1215A-L Extreme S-Cam Bushing Kit (15-5/8" S-2" Bore, Left-Hand) Cam,

C1215O-L Extreme S-Cam Bushing Kit (15-5/8" S-Cam, **Oversized** 2.01" Bore, Left-Hand)

C1215A-R

Extreme S-Cam Bushing Kit (15-5/8" S-2" Bore, Right-Hand)

C1215O-R

Extreme S-Cam Bushing Kit (15-5/8" S-

Cam,

Oversized 2.01" Bore, Right-Hand)





C1115A-L

Extreme S-Cam Bushing Kit (15-5/8" S- C1115A-R Cam, 1-7/8" Bore, Left-Hand)

Extreme S-Cam Bushing Kit (15-5/8" S-1-7/8" Bore, Right-Hand)

www.extremebrake.com





15" REPLACEMENT TUBE KITS

except the s-cam: enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set. Extreme Cam Tubes (-TUBE) do not include the mounting bracket set or washer/spacer set.





C1215A-RTK Extreme Cam Enclosure Tube Kit for C1215A-TUBE Extreme Cam Enclosure Tube for 15-

15-5/8" S-Cam (No S-Cam Included),

2" Bore

C1215O-RTK Extreme Cam Enclosure Tube Kit for C1215O-TUBE Extreme Cam Enclosure Tube for 15-

15-5/8" S-Cam (No S-Cam Included),

Oversized 2.01" Bore

Extreme Cam Enclosure Tube for 15-5/8" S-Cam (No S-Cam Included), 2"

Extreme Cam Enclosure Tube for 15-5/8" S-Cam (No S-Cam Included),

Oversized 2.01" Bore





C1115A-RTK Extreme Cam Enclosure Tube Kit for C1115A-TUBE 15-5/8" S-Cam (No S-Cam Included), 1-7/8" Bore

Extreme Cam Enclosure Tube for 15-5/8" S-Cam (No S-Cam Included), 1-7/8" Bore

www.extremebrake.com





16" 28-SPLINE S-CAM FULL KITS

Extreme Cam left-hand and right-hand (-L and -R) kits include the s-cam, enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set.





C1216A-L Extreme S-Cam Bushing Kit (16-5/16" S-Cam, 2" Bore, Left-Hand)

C1216O-L Extreme S-Cam Bushing Kit (16-5/16" S-Cam, Oversized 2.01" Bore, Left-Hand)

C1216A-R

Extreme S-Cam Bushing Kit (16-5/16" S-Cam, 2" Bore, Right-Hand)

C1216O-R

Extreme S-Cam Bushing Kit (16-5/16" S-Cam, **Oversized** 2.01" Bore, Right-Hand)





C1116A-L Extreme S-Cam Bushing Kit (16-5/16" S-Cam, 1-7/8" Bore, Left-Hand)

C1116A-R

Extreme S-Cam Bushing Kit (16-5/16" S-Cam, 1-7/8" Bore, Right-Hand)

www.extremebrake.com





16" REPLACEMENT TUBE KITS

Extreme Cam Replacement Tube Kits (-RTK) contain everything from the original -L and -R kits except the s-cam: enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set. Extreme Cam Tubes (-TUBE) do not include the mounting bracket set or washer/spacer set.





C1216A-RTK Extreme Cam Enclosure Tube Kit for C1216A-TUBE Extreme Cam Enclosure Tube for 16-

16-5/16" S-Cam (No S-Cam Included),

2" Bore

C1216O-RTK Extreme Cam Enclosure Tube Kit for C1216O-TUBE Extreme Cam Enclosure Tube for 16-

16-5/16" S-Cam (No S-Cam Included),

Oversized 2.01" Bore

5/16" S-Cam (No S-Cam Included), 2" Bore

5/16" S-Cam (No S-Cam Included),

Oversized 2.01" Bore





C1116A-RTK Extreme Cam Enclosure Tube Kit for C1116A-TUBE 16-5/16" S-Cam (No S-Cam Included), 1-7/8" Bore

Extreme Cam Enclosure Tube for 16-5/16" S-Cam (No S-Cam Included), 1-7/8" Bore

www.extremebrake.com





17" 28-SPLINE S-CAM FULL KITS

Extreme Cam left-hand and right-hand (-L and -R) kits include the s-cam, enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set.





C1217A-L Extreme S-Cam Bushing Kit (17-7/16" S-Cam, 2" Bore, Left-Hand)

C1217O-L Extreme S-Cam Bushing Kit (17-7/16" S-Cam, **Oversized** 2.01" Bore, Left-Hand)

C1217A-R

Extreme S-Cam Bushing Kit (17-7/16" S-Cam, 2" Bore, Right-Hand)

Extreme S-Cam Bushing Kit (17-7/16" S-C1217O-R

Cam, **Oversized** 2.01" Bore, Right-Hand)





C1117A-L Extreme S-Cam Bushing Kit (17-7/16" S-Cam, 1-7/8" Bore, Left-Hand)

C1117A-R

Extreme S-Cam Bushing Kit (17-7/16" S-1-7/8" Bore, Right-Hand)

www.extremebrake.com





17" REPLACEMENT TUBE KITS

except the s-cam: enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set. Extreme Cam Tubes (-TUBE) do not include the mounting bracket set or washer/spacer set.





C1217A-RTK Extreme Cam Enclosure Tube Kit for C1217A-TUBE Extreme Cam Enclosure Tube for 17-

17-7/16" S-Cam (No S-Cam Included),

2" Bore

C1217O-RTK Extreme Cam Enclosure Tube Kit for C1217O-TUBE Extreme Cam Enclosure Tube for 17-

17-7/16" S-Cam (No S-Cam Included),

Oversized 2.01" Bore

Extreme Cam Enclosure Tube for 17-7/16" S-Cam (No S-Cam Included), 2"

Extreme Cam Enclosure Tube for 17-7/16" S-Cam (No S-Cam Included).

Oversized 2.01" Bore





C1117A-RTK Extreme Cam Enclosure Tube Kit for C1117A-TUBE 17-7/16" S-Cam (No S-Cam Included), 1-7/8" Bore

Extreme Cam Enclosure Tube for 17-7/16" S-Cam (No S-Cam Included), 1-7/8" Bore

www.extremebrake.com





18" 28-SPLINE S-CAM FULL KITS

Extreme Cam left-hand and right-hand (-L and -R) kits include the s-cam, enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set.





C1218A-L Extreme S-Cam Bushing Kit (18-5/8" S-Cam. 2" Bore, Left-Hand)

C1218O-L Extreme S-Cam Bushing Kit (18-5/8" S-

Cam, **Oversized** 2.01" Bore, Left-Hand)

C1218A-R

Extreme S-Cam Bushing Kit (18-5/8" S-

Cam, 2" Bore, Right-Hand)

Extreme S-Cam Bushing Kit (18-5/8" S-C1218O-R

Cam, **Oversized** 2.01" Bore, Right-Hand)





C1118A-L Extreme S-Cam Bushing Kit (18-5/8" S- C1118A-R Cam, 1-7/8" Bore, Left-Hand)

Extreme S-Cam Bushing Kit (18-5/8" S-1-7/8" Bore, Right-Hand) Cam.

www.extremebrake.com





18" REPLACEMENT TUBE KITS

except the s-cam: enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set. Extreme Cam Tubes (-TUBE) do not include the mounting bracket set or washer/spacer set.





C1218A-RTK Extreme Cam Enclosure Tube Kit for C1218A-TUBE Extreme Cam Enclosure Tube for 18-

18-5/8" S-Cam (No S-Cam Included),

2" Bore

C1218O-RTK Extreme Cam Enclosure Tube Kit for C1218O-TUBE Extreme Cam Enclosure Tube for 18-

18-5/8" S-Cam (No S-Cam Included),

Oversized 2.01" Bore

Extreme Cam Enclosure Tube for 18-5/8" S-Cam (No S-Cam Included), 2" Bore

Extreme Cam Enclosure Tube for 18-5/8" S-Cam (No S-Cam Included),

Oversized 2.01" Bore





C1118A-RTK Extreme Cam Enclosure Tube Kit for C1118A-TUBE 18-5/8" S-Cam (No S-Cam Included), 1-7/8" Bore

Extreme Cam Enclosure Tube for 18-5/8" S-Cam (No S-Cam Included), 1-7/8" Bore

www.extremebrake.com





19" 28-SPLINE S-CAM FULL KITS

Extreme Cam left-hand and right-hand (-L and -R) kits include the s-cam, enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set.





C1219A-L Extreme S-Cam Bushing Kit (19-1/2" S-

Cam,

2" Bore, Left-Hand)

C1219O-L Extreme S-Cam Bushing Kit (19-1/2" S-

Cam, **Oversized** 2.01" Bore, Left-Hand)

C1219A-R Extreme S-Cam Bushing Kit (19-1/2" S-

Cam,

2" Bore, Right-Hand)

C1219O-R Extreme S-Cam Bushing Kit (19-1/2" S-

Cam,

Oversized 2.01" Bore, Right-Hand)





C1119A-L Extreme S-Cam Bushing Kit (19-1/2" S-

Cam,

1-7/8" Bore, Left-Hand)

C1119A-R

Extreme S-Cam Bushing Kit (19-1/2" S-Cam 1-7/8" Bore, Right-Hand)

www.extremebrake.com





19" REPLACEMENT TUBE KITS

except the s-cam: enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set. Extreme Cam Tubes (-TUBE) do not include the mounting bracket set or washer/spacer set.





C1219A-RTK Extreme Cam Enclosure Tube Kit for C1219A-TUBE Extreme Cam Enclosure Tube for 19-

19-1/2" S-Cam (No S-Cam Included), 2"

Bore

C1219O-RTK Extreme Cam Enclosure Tube Kit for C1219O-TUBE Extreme Cam Enclosure Tube for 19-

19-1/2" S-Cam (No S-Cam Included),

Oversized 2.01" Bore

Extreme Cam Enclosure Tube for 19-1/2" S-Cam (No S-Cam Included), 2" Bore

Extreme Cam Enclosure Tube for 19-1/2" S-Cam (No S-Cam Included),

Oversized 2.01" Bore





C1119A-RTK Extreme Cam Enclosure Tube Kit for C1119A-TUBE
19-1/2" S-Cam (No S-Cam Included), 17/8" Bore

Extreme Cam Enclosure Tube for 19-1/2" S-Cam (No S-Cam Included), 1-7/8" Bore

www.extremebrake.com





20" 28-SPLINE S-CAM FULL KITS

Extreme Cam left-hand and right-hand (-L and -R) kits include the s-cam, enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set.





C1220A-L Extreme S-Cam Bushing Kit (20-7/16" S-

Cam,

2" Bore, Left-Hand)

C1220O-L Extreme S-Cam Bushing Kit (20-7/16" S-

Cam, **Oversized** 2.01" Bore, Left-Hand)

C1220A-R

Extreme S-Cam Bushing Kit (20-7/16" S-

Cam,

2" Bore, Right-Hand)

C1220O-R Extreme S-Cam Bushing Kit (20-7/16" S-

Cam, **Oversized** 2.01" Bore, Right-Hand)





C1120A-L Extreme S-Cam Bushing Kit (20-7/16" S-Cam,

1-7/8" Bore, Left-Hand)

C1120A-R

Extreme S-Cam Bushing Kit (20-7/16" S-Carn, 1-7/8" Bore, Right-Hand)

www.extremebrake.com





20" REPLACEMENT TUBE KITS

except the s-cam: enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set. Extreme Cam Tubes (-TUBE) do not include the mounting bracket set or washer/spacer set.





C1220A-RTK Extreme Cam Enclosure Tube Kit for C1220A-TUBE Extreme Cam Enclosure Tube for 20-

20-7/16" S-Cam (No S-Cam Included),

2" Bore

C1220O-RTK Extreme Cam Enclosure Tube Kit for C1220O-TUBE Extreme Cam Enclosure Tube for 20-

20-7/16" S-Cam (No S-Cam Included),

Oversized 2.01" Bore

Extreme Cam Enclosure Tube for 20-7/16" S-Cam (No S-Cam Included), 2"

Bore

7/16" S-Cam (No S-Cam Included),

Oversized 2.01" Bore





C1120A-RTK Extreme Cam Enclosure Tube Kit for C1120A-TUBE 20-7/16" S-Cam (No S-Cam Included),

1-7/8" Bore

Extreme Cam Enclosure Tube for 20-7/16" S-Cam (No S-Cam Included), 1-7/8" Bore

www.extremebrake.com





21" 28-SPLINE S-CAM FULL KITS

Extreme Cam left-hand and right-hand (-L and -R) kits include the s-cam, enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set.





C1221A-L Extreme S-Cam Bushing Kit (21-1/8" S-Cam,

2" Bore, Left-Hand)

C1221O-L Extreme S-Cam Bushing Kit (21-1/8" S-

Cam, **Oversized** 2.01" Bore, Left-Hand)

C1221A-R Extreme S-Cam Bushing Kit (21-1/8" S-

Cam,

2" Bore, Right-Hand)

C1221O-R Extreme S-Cam Bushing Kit (21-1/8" S-

Cam, **Oversized** 2.01" Bore, Right-Hand)





C1121A-L Extreme S-Cam Bushing Kit (21-1/8" S-Cam,

1-7/8" Bore, Left-Hand)

C1121A-R

Extreme S-Cam Bushing Kit (21-1/8" S-Cam, 1-7/8" Bore, Right-Hand)

www.extremebrake.com





21" REPLACEMENT TUBE KITS

Extreme Cam Replacement Tube Kits (-RTK) contain everything from the original -L and -R kits except the s-cam: enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set. Extreme Cam Tubes (-TUBE) do not include the mounting bracket set or washer/spacer set.





C1221A-RTK Extreme Cam Enclosure Tube Kit for C1221A-TUBE Extreme Cam Enclosure Tube for 21-

21-1/8" S-Cam (No S-Cam Included), 2"

C1221O-RTK Extreme Cam Enclosure Tube Kit for C1221O-TUBE Extreme Cam Enclosure Tube for 21-

21-1/8" S-Cam (No S-Cam Included),

Oversized 2.01" Bore

1/8" S-Cam (No S-Cam Included), 2" Bore

1/8" S-Cam (No S-Cam Included),

Oversized 2.01" Bore





C1121A-RTK Extreme Cam Enclosure Tube Kit for C1121A-TUBE

21-1/8" S-Cam (No S-Cam Included), 1-7/8" Bore

Extreme Cam Enclosure Tube for 21-1/8" S-Cam (No S-Cam Included), 1-7/8" Bore

www.extremebrake.com





22" 28-SPLINE S-CAM FULL KITS

Extreme Cam left-hand and right-hand (-L and -R) kits include the s-cam, enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set.





C1222A-L Extreme S-Cam Bushing Kit (22-3/8" S-Cam,

2" Bore, Left-Hand)

C1222O-L Extreme S-Cam Bushing Kit (22-3/8" S-

Cam, **Oversized** 2.01" Bore, Left-Hand)

C1222A-R Extreme S-Cam Bushing Kit (22-3/8" S-

Cam,

2" Bore, Right-Hand)

C1222O-R Extreme S-Cam Bushing Kit (22-3/8" S-

Cam, **Oversized** 2.01" Bore, Right-Hand)





C1122A-L Extreme S-Cam Bushing Kit (22-3/8" S-Cam, 1-7/8" Bore, Left-Hand) C1122A-R

Extreme S-Cam Bushing Kit (22-3/8" S-Cam 1-7/8" Bore, Right-Hand)

www.extremebrake.com





22" REPLACEMENT TUBE KITS

Extreme Cam Replacement Tube Kits (-RTK) contain everything from the original -L and -R kits except the s-cam: enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set. Extreme Cam Tubes (-TUBE) do not include the mounting bracket set or washer/spacer set.





C1222A-RTK Extreme Cam Enclosure Tube Kit for C1222A-TUBE Extreme Cam Enclosure Tube for 22-

22-3/8" S-Cam (No S-Cam Included),

2" Bore

C1222O-RTK Extreme Cam Enclosure Tube Kit for C1222O-TUBE Extreme Cam Enclosure Tube for 22-

22-3/8" S-Cam (No S-Cam Included),

Oversized 2.01" Bore

3/8" S-Cam (No S-Cam Included), 2"

3/8" S-Cam (No S-Cam Included),

Oversized 2.01" Bore





C1122A-RTK Extreme Cam Enclosure Tube Kit for C1122A-TUBE

22-3/8" S-Cam (No S-Cam Included),

1-7/8" Bore

Extreme Cam Enclosure Tube for 22-3/8" S-Cam (No S-Cam Included), 1-7/8" Bore

www.extremebrake.com





23" 28-SPLINE S-CAM FULL KITS

Extreme Cam left-hand and right-hand (-L and -R) kits include the s-cam, enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set.



C1223A-L Extreme S-Cam Bushing Kit (23-7/8" S-Cam,

2" Bore, Left-Hand)

C1223O-L Extreme S-Cam Bushing Kit (23-7/8" S-

Cam, **Oversized** 2.01" Bore, Left-Hand)



C1223A-R Extreme S-Cam Bushing Kit (23-7/8" S-

2" Bore, Right-Hand)

Extreme S-Cam Bushing Kit (23-7/8" S-C1223O-R

Cam, **Oversized** 2.01" Bore, Right-Hand)



C1123A-L Extreme S-Cam Bushing Kit (23-7/8" S-Cam.

1-7/8" Bore, Left-Hand)



C1123A-R

Extreme S-Cam Bushing Kit (23-7/8" S-Cam 1-7/8" Bore, Right-Hand)

www.extremebrake.com





23" REPLACEMENT TUBE KITS

Extreme Cam Replacement Tube Kits (-RTK) contain everything from the original -L and -R kits except the s-cam: enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set. Extreme Cam Tubes (-TUBE) do not include the mounting bracket set or washer/spacer set.





C1223A-RTK Extreme Cam Enclosure Tube Kit for C1223A-TUBE Extreme Cam Enclosure Tube for 23-

23-7/8" S-Cam (No S-Cam Included),

C1223O-RTK Extreme Cam Enclosure Tube Kit for C1223O-TUBE Extreme Cam Enclosure Tube for 23-

23-7/8" S-Cam (No S-Cam Included),

Oversized 2.01" Bore

7/8" S-Cam (No S-Cam Included), 2"

7/8" S-Cam (No S-Cam Included),

Oversized 2.01" Bore





C1123A-RTK Extreme Cam Enclosure Tube Kit for C1123A-TUBE 23-7/8" S-Cam (No S-Cam Included),

1-7/8" Bore

Extreme Cam Enclosure Tube for 23-7/8" S-Cam (No S-Cam Included), 1-7/8" Bore

www.extremebrake.com





24" 28-SPLINE S-CAM FULL KITS

Extreme Cam left-hand and right-hand (-L and -R) kits include the s-cam, enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set.





C1224A-L Extreme S-Cam Bushing Kit (24-3/8" S-Cam,

2" Bore, Left-Hand)

C1224O-L Extreme S-Cam Bushing Kit (24-3/8" S-

Cam, **Oversized** 2.01" Bore, Left-Hand)

C1224A-R Extreme S-Cam Bushing Kit (24-3/8" S-Cam,

2" Bore, Right-Hand)

Extreme S-Cam Bushing Kit (24-3/8" S-C1224O-R

Cam, **Oversized** 2.01" Bore, Right-Hand)





C1124A-L Extreme S-Cam Bushing Kit (24-3/8" S-Cam, 1-7/8" Bore, Left-Hand)

C1124A-R

Extreme S-Cam Bushing Kit (24-3/8" S-Cam, 1-7/8" Bore, Right-Hand)

www.extremebrake.com





24" REPLACEMENT TUBE KITS

Extreme Cam Replacement Tube Kits (-RTK) contain everything from the original -L and -R kits except the s-cam: enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set. Extreme Cam Tubes (-TUBE) do not include the mounting bracket set or washer/spacer set.





C1224A-RTK Extreme Cam Enclosure Tube Kit for C1224A-TUBE Extreme Cam Enclosure Tube for 24-

24-3/8" S-Cam (No S-Cam Included),

2" Bore

C1224O-RTK Extreme Cam Enclosure Tube Kit 24- C1224O-TUBE Extreme Cam Enclosure Tube for 24-

3/8" S-Cam (No S-Cam Included).

Oversized 2.01" Bore

3/8" S-Cam (No S-Cam Included), 2"

Bore

3/8" S-Cam (No S-Cam Included).

Oversized 2.01" Bore





C1124A-RTK Extreme Cam Enclosure Tube Kit for C1124A-TUBE

24-3/8" S-Cam (No S-Cam Included), 1-7/8" Bore

Extreme Cam Enclosure Tube for 24-3/8" S-Cam (No S-Cam Included), 1-7/8" Bore

www.extremebrake.com





25" 28-SPLINE S-CAM FULL KITS

Extreme Cam left-hand and right-hand (-L and -R) kits include the s-cam, enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set.



C1225A-L Extreme S-Cam Bushing Kit (25-3/8" S-

Cam,

2" Bore, Left-Hand)

C1225O-L Extreme S-Cam Bushing Kit (25-3/8" S-

Cam, **Oversized** 2.01" Bore, Left-Hand)



C1225A-R Extreme S-Cam Bushing Kit (25-3/8" S-

Cam,

2" Bore, Right-Hand)

C1225O-R Extreme S-Cam Bushing Kit (25-3/8" S-

Cam, **Oversized** 2.01" Bore, Right-Hand)



C1125A-L Extreme S-Cam Bushing Kit (25-3/8" S-Cam.

1-7/8" Bore, Left-Hand)



C1125A-R

Extreme S-Cam Bushing Kit (25-3/8" S-Cam 1-7/8" Bore, Right-Hand)

www.extremebrake.com





25" REPLACEMENT TUBE KITS

except the s-cam: enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set. Extreme Cam Tubes (-TUBE) do not include the mounting bracket set or washer/spacer set.





C1225A-RTK Extreme Cam Enclosure Tube Kit for C1225A-TUBE Extreme Cam Enclosure Tube for 25-

25-3/8" S-Cam (No S-Cam Included),

2" Bore

C1225O-RTK Extreme Cam Enclosure Tube Kit 25- C1225O-TUBE Extreme Cam Enclosure Tube for 25-

3/8" S-Cam (No S-Cam Included),

Oversized 2.01" Bore

Extreme Cam Enclosure Tube for 25-3/8" S-Cam (No S-Cam Included), 2"

Bore

Extreme Cam Enclosure Tube for 25-3/8" S-Cam (No S-Cam Included),

Oversized 2.01" Bore





C1125A-RTK Extreme Cam Enclosure Tube Kit for C1125A-TUBE 25-3/8" S-Cam (No S-Cam Included),

1-7/8" Bore

EXTREM

Extreme Cam Enclosure Tube for 25-3/8" S-Cam (No S-Cam Included), 1-7/8" Bore

888-844-7734 | Page 31

www.extremebrake.com



26" 28-SPLINE S-CAM FULL KITS

Extreme Cam left-hand and right-hand (-L and -R) kits include the s-cam, enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set.



C1226A-L Extreme S-Cam Bushing Kit (26-1/2" S-

Cam,

2" Bore, Left-Hand)

C1226O-L Extreme S-Cam Bushing Kit (26-1/2" S-

Cam, **Oversized** 2.01" Bore, Left-Hand)



C1226A-R Extreme S-Cam Bushing Kit (26-1/2" S-

Cam.

2" Bore, Right-Hand)

C1226O-R Extreme S-Cam Bushing Kit (26-1/2" S-

Cam, **Oversized** 2.01" Bore, Right-Hand)



C1126A-L Extreme S-Cam Bushing Kit (26-1/2" S-Cam,

1-7/8" Bore, Left-Hand)



C1126A-R

Extreme S-Cam Bushing Kit (26-1/2" S-Cam 1-7/8" Bore, Right-Hand)

www.extremebrake.com





26" REPLACEMENT TUBE KITS

except the s-cam: enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set. Extreme Cam Tubes (-TUBE) do not include the mounting bracket set or washer/spacer set.





C1226A-RTK Extreme Cam Enclosure Tube Kit for C1226A-TUBE Extreme Cam Enclosure Tube for 26-

26-1/2" S-Cam (No S-Cam Included),

2" Bore

C1226O-RTK Extreme Cam Enclosure Tube Kit 26- C1226O-TUBE Extreme Cam Enclosure Tube for 26-

1/2" S-Cam (No S-Cam Included),

Oversized 2.01" Bore

Extreme Cam Enclosure Tube for 26 1/2" S-Cam (No S-Cam Included), 2" Bore

POLE

Extreme Cam Enclosure Tube for 26-1/2" S-Cam (No S-Cam Included),

Oversized 2.01" Bore





C1126A-RTK Extreme Cam Enclosure Tube Kit for C1126A-TUBE 26-1/2" S-Cam (No S-Cam Included),

1-7/8" Bore

Extreme Cam Enclosure Tube for 26-1/2" S-Cam (No S-Cam Included), 1-7/8" Bore

www.extremebrake.com





30" 28-SPLINE S-CAM FULL KITS

Extreme Cam left-hand and right-hand (-L and -R) kits include the s-cam, enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set.



C1230A-L Extreme S-Cam Bushing Kit (30-1/4" S-Cam,

-aiii,

2" Bore, Left-Hand)

C1230O-L Extreme S-Cam Bushing Kit (30-1/4" S-

Cam, **Oversized** 2.01" Bore, Left-Hand)

C1230A-R Extreme S-Cam Bushing Kit (30-1/4" S-

Cam,

2" Bore, Right-Hand)

C1230O-R Extreme S-Cam Bushing Kit (30-1/4" S-

Cam, **Oversized** 2.01" Bore, Right-Hand)





C1130A-L Extreme S-Cam Bushing Kit (30-1/4" S-Cam, 1-7/8" Bore, Left-Hand) C1130A-R

Extreme S-Cam Bushing Kit (30-1/4" S-Cam 1-7/8" Bore, Right-Hand)

www.extremebrake.com





30" REPLACEMENT TUBE KITS

Extreme Cam Replacement Tube Kits (-RTK) contain everything from the original -L and -R kits except the s-cam: enclosed cam tube with built-in bushing, seals, and grease fittings, mounting bracket set, and washer/spacer set. Extreme Cam Tubes (-TUBE) do not include the mounting bracket set or washer/spacer set.





C1230A-RTK Extreme Cam Enclosure Tube Kit for C1230A-TUBE Extreme Cam Enclosure Tube for 30-

30-1/4" S-Cam (No S-Cam Included).

C1230O-RTK Extreme Cam Enclosure Tube Kit 30- C1230O-TUBE Extreme Cam Enclosure Tube for 30-

1/4" S-Cam (No S-Cam Included),

Oversized 2.01" Bore

1/4" S-Cam (No S-Cam Included), 2"

1/4" S-Cam (No S-Cam Included),

Oversized 2.01" Bore





C1130A-RTK Extreme Cam Enclosure Tube Kit for C1130A-TUBE 30-1/4" S-Cam (No S-Cam Included),

1-7/8" Bore

Extreme Cam Enclosure Tube for 30-1/4" S-Cam (No S-Cam Included), 1-7/8" Bore

www.extremebrake.com





EXTREME S-CAMS - 28 SPLINE

Extreme S-Cams are left-hand (-L) and right-hand (-R) brake camshafts for multiple applications and have an s-cam journal of 1.5" continuous, and Q/Q+ style s-head with a measurement of 1-1/16".

Note: The Part Numbers for all s-cams are engraved on the spline end of the scam.









S-02-011-L

Extreme S-Cam Only (11-1/32" 28-Spline, Left-Hand Camshaft)

S-02-011-R Extreme S-Cam Only (11-1/32" 28-Spline, Right-Hand Camshaft)

EXTREME S-CAMS - 10 SPLINE





S-C2-011-L

Extreme S-Cam Only (11-1/32" 10-Spline, S-C2-011-R Extreme S-Cam Only (11-1/32" 10-Left-Hand Camshaft)

Spline, Right-Hand Camshaft)

www.extremebrake.com





EXTREME S-CAMS - 28 SPLINE

Extreme S-Cams are left-hand (-L) and right-hand (-R) brake camshafts for multiple applications and have an s-cam journal of 1.5" continuous, and Q/Q+ style s-head with a measurement of 1-1/16".

Note: Part # for all s-cams are engraved on the spline end of the s-cam.





S-02-015-L	Extreme S-Cam Only (15-5/8" 28-Spline, Left-Hand Camshaft)	S-02-015-R	Extreme S-Cam Only (15-5/8" 28-Spline, Right-Hand Camshaft)
S-02-016-L	Extreme S-Cam Only (16-5/16" 28-Spline, Left-Hand Camshaft)	S-02-016-R	Extreme S-Cam Only (16-5/6" 28-Spline, Right-Hand Camshaft)
S-02-017-L	Extreme S-Cam Only (17-7/16" 28-Spline, Left-Hand Camshaft)	S-02-017-R	Extreme S-Cam Only (17-7/16" 28-Spline, Right-Hand Camshaft)
S-02-018-L	Extreme S-Cam Only (18-5/8" 28-Spline, Left-Hand Camshaft)	S-02-018-R	Extreme S-Cam Only (18-5/8" 28-Spline, Right-Hand Camshaft)
S-02-019-L	Extreme S-Cam Only (19-1/2" 28-Spline, Left-Hand Camshaft)	S-02-019-R	Extreme S-Cam Only (19-1/2" 28-Spline, Right-Hand Camshaft)
S-02-020-L	Extreme S-Cam Only (20-7/16" 28-Spline, Left-Hand Camshaft)	S-02-020-R	Extreme S-Cam Only (20-7/16" 28-Spline, Right-Hand Camshaft)
S-02-021-L	Extreme S-Cam Only (21-1/8" 28-Spline, Left-Hand Camshaft)	S-02-021-R	Extreme S-Cam Only (21-1/8" 28-Spline, Right-Hand Camshaft)
S-02-022-L	Extreme S-Cam Only (22-3/8" 28-Spline, Left-Hand Camshaft)	S-02-022-R	Extreme S-Cam Only (22-3/8" 28-Spline, Right-Hand Camshaft)
S-02-023-L	Extreme S-Cam Only (23-7/8" 28-Spline, Left-Hand Camshaft)	S-02-023-R	Extreme S-Cam Only (23-7/8" 28-Spline, Right-Hand Camshaft)
S-02-024-L	Extreme S-Cam Only (24-3/8" 28-Spline, Left-Hand Camshaft)	S-02-024-R	Extreme S-Cam Only (24-3/8" 28-Spline, Right-Hand Camshaft)
S-02-025-L	Extreme S-Cam Only (25-3/8" 28-Spline, Left-Hand Camshaft)	S-02-025-R	Extreme S-Cam Only (25-3/8" 28-Spline, Right-Hand Camshaft)
S-02-026-L	Extreme S-Cam Only (26-1/2" 28-Spline, Left-Hand Camshaft)	S-02-026-R	Extreme S-Cam Only (26-1/2" 28-Spline, Right-Hand Camshaft)
S-02-030-L	Extreme S-Cam Only (30-1/4" 28-Spline, Left-Hand Camshaft)	S-02-030-R	Extreme S-Cam Only (30-1/4" 28-Spline, Right-Hand Camshaft)

www.extremebrake.com





EXTREME CAM ACCESSORIES







C089K

Extreme Cam Bolt-On Adapter Bracket Kit

CM-187

Extreme Cam Universal Mounting Bracket Kit

CM-185

Extreme S-Cam Only (15-5/8" 28-Spline, Left-Hand Camshaft)







CM-152K

Extreme Cam Pressure Relief Kit (Package of 10)

CM-153K

Extreme Cam Seals Kit (Package of 2)

CM-190K

Extreme Cam Repair Kit

www.extremebrake.com

