



JK REAR BUMPSTOP FOR 3"-6" LIFTS

Thank you for choosing Rough Country for your suspension needs.

Please read instructions before beginning installation. Check the kit hardware against the parts list. Be sure you have all needed parts and know where they go. Also please review tools needed list and make sure you have needed tools. If question exist we will be happy to answer any questions concerning the design, function, and correct use of our products by calling 1-800-222-7023.

Please note the position of the spacer on the axle in the pictures below. This rear bump stop spacer can be used for 3" to 6" lifts. The spacer will be installed as shown on 3"-4" lifts and on 5"-6" kits the spacer will be turned on the side for installation.

Parts Included:

- 2-Bump Stop Brackets
- 1-Poly Bag Containing:
 - 4-3/8" x 3/4" Bolts
 - 4-Flange Lock Nuts
 - 4-Flat Washers



- ### Tools Needed:
- 9/16" Socket/ Wrench

INSTALLATION INSTRUCTIONS

1. Install the bump stop spacers as shown on axle and secure with the supplied 3/8" x 3/4" bolts, washers and nuts. Tighten using a 9/16" socket / wrench. **See Photo 1** for installation on vehicles equipped with 3-4" suspension lifts and **Photo 2** for 5-6" suspension lifts.



POST INSTALLATION

All components must be retightened after 500 miles, and every three thousand miles after installation.

Thank you for using Rough Country Suspension for your off road needs!!