



88-98 Chevy/GMC 1500 Torsion Bar Adjuster Kit

Thank you for choosing Rough Country Off Road Gear for your suspension needs.

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

PLEASE READ INSTRUCTIONS BEFORE BEGINNING INSTALATION.

PRODUCT USE INFORMATION

As a general rule, the taller a vehicle is, the easier it will roll. Offset, as much as possible, what is lost in rollover resistance by increasing tire track width. In other words, go "wide" as you go "tall".

Do not add, alter, or fabricate any factory or after-market parts to increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands, lifts, and/or combining body lift with suspension lifts voids all warranties. Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered.

Braking performance and capability are decreased when significantly larger/heavier tires and wheels are used. Take this into consideration while driving.

The required installation time for this system is approximately 2 hours (see recommended tool list shown below). This kit is usually sold as a front end leveling kit, but can be sold in combination with rear blocks and u-bolts or a rear add-a-leaf. Shocks with longer travel are recommended.

This suspension system was developed using 285x75R16 tire on an 8" wheel. Before installing other combinations, please consult your local tire and wheel specialist.

If questions exist we will be happy to answer any questions concerning the design, function, and correct use of our products.

NOTICE TO DEALER AND VEHICLE OWNER

Any vehicle equipped with any Rough Country product should have a "Warning to Driver" decal installed on the inside of the windshield or on the vehicle's dash. The decal should act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics.

INSTALLING DEALER - it is your responsibility to install the warning decal and forward these installation instructions on to the vehicle owner for review. These instructions should be kept in the vehicle for its service.

KIT CONTENTS


Torsion Bar Adjusters (2)

RECOMMENDED TOOLS

Floor Jack
Heavy Duty Jack Stands
Safety Glasses
Wheel Chock
Torsion Bar Puller Tool
Impact Wrench
18mm Socket

INSTALLATION INSTRUCTIONS

1. Place the vehicle in neutral. Raise the front of the vehicle with a jack to slightly raise the tires off the ground and support the frame with jack stands beneath each frame rail behind the lower control arms. Installation is done one side at a time, starting with the driver side. The torsion bar adjusters are under the cab of the vehicle at the rearward end of the torsion bars.
2. Measure or make a note of how much thread is remaining on the torsion bar adjuster bolt. You will reset the bars at this same location with the new adjusters. Use extreme caution when loading and unloading the torsion bars; there is a tremendous amount of energy stored in them. Keep your hands and body clear of the adjuster arm assembly and the puller tool in case anything slips or breaks. Note: Because of the extreme loads generated by the torsion bars on these vehicles, a standard tow-jaw puller may bend the "lips" of the cross member and pop out of place. For best results use a torsion bar puller tool. If you cannot find one locally, this tool (J-22517-C) is available from Kent Moore Tools in Roseville, Michigan (800-345-2233) or a Ball Joint Remover like OTC7249 can be used.
3. On the driver side, using a torsion bar removal tool, remove the stock torsion bar adjuster. Loading the torsion bar using the tool, removing the bolt and nut block, does this. Unload the bar; slide the torsion bar forward allowing the OE torsion key to fall out.
4. Install the new torsion bar adjuster using the torsion bar tool. Reinstall the threaded block and adjuster bolt.
5. Repeat steps for passenger side. Making sure the driver and passenger side torsion bar adjuster bolts are adjusted the same amount. Fine-tuning is done in a later step.
6. After the torsion bar adjusters have been installed and tightened to the factory measurement taken in step #2.
7. Jack up the front of the vehicle and remove the jack stands. Lower the vehicle to the ground to where the torsion bars are supporting the weight of the vehicle. Check for level.
8. Additional adjustment may need to be performed to level the vehicle by either tightening or loosening the torsion bars. This is done with a floor jack supporting the side of the vehicle that is being adjusted, raising the tires slightly off the ground and only adjusting the bolt 1-2 turns at a time to ensure the leveling of the truck. After adjustment lower the vehicle to the ground and recheck for level. This may take several attempts.
9. Remove the stock shock absorbers at this time and install the new Rough Country shocks if purchased with kit.



This kit will level the vehicle without a substantial difference in ride quality. Most customers adjust the front to 2" higher than stock, and are satisfied with the ride quality. Ride quality is inversely proportional to heights ABOVE a 2" adjustment. This leveling kit works within the range of the FACTORY droop, or downward suspension cycle. It does NOT bind the CV axles or ball joints, just as none of these conditions occur with the truck supported on a hoist and the front wheels hanging freely in the air. As with any lift installed, adjustment of the front headlights is required after installation. Note – the air dam on the front may need to be trimmed for additional clearance, depending on the tire size.

A front-end alignment should ALWAYS be checked after installing ANY vehicle suspension lift. This kit typically requires a slight toe-in adjustment. Record the ride height measurement at the time of alignment. If, in the future the torsion bars settle excessively, alignment can be restored by adjusting-up the bars to their original ride height.

